

AIYAPLAY

IN250400073V01_UK

370-394V70



Max.inflate to 40 psi
(280 Kpa)

Electric kids' car



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

INSTRUCTION MANUAL

Please read the manual before using the product. The manual and carton contain important information, please keep them properly for later references. If failure to follow the instruction in the manual, it might be dangerous for your child.

In order to improve the product and quality, we may change the parts of structure, appearance, packing method, assembly method and function of the product without any notice. When there is any difference between the manual and the product, please subject to the actual product. We are sorry for any inconvenience.










Model identifie		
Input voltage	100-240~	V
Input AC frequency	50/60	Hz
Output voltage	≡ 24	V
Output current	1.0	A
Output power	/	W
Average active efficiency	86.2	%
Efficiency at low load (10 %)	77	%
No-load power consumption	0. 10	W




WARNING:

Products should be assembled by an adult. Protective equipment should be worn. Not to be used in traffic. This toy is unsuitable for children under 6 years due to its maximum speed. Choking hazard-small parts. In unassembled state, contains potentially hazardous small parts. Please keep out of the reach of small children. Pay attention to the potential hazards of using the toy in areas other than private grounds.

Warning: *The manual and carton contain important information, please keep them properly for later references.*

No.	Parts Name	QTY	PICTURE
①	Car Body	1	
②	Fender	1	
③	Front wheel	1	
④	Seat	1	
⑤	Wrench	1	
⑥	M5*50 screw bolt (on the fender)	1	
⑦	M5 nut (on the fender)	1	
⑧	Charger	1	
⑨	User manual	1	



Tools:



Cross screwdriver
(Not included)



Adjustable wrench
(Not Included)



5



8



9

Disclaimer:

The pictures in this instruction are for assembly reference only. Please refer to the actual product.

Warning: This product is not the vehicle for transportation, it should be used under adult guidance. Parents should ensure that children have taken the safety measures before use.

Warning: The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third party.

Warning: This toy produces flashes that may trigger epilepsy in sensitised individuals

Warning: Not suitable for children under 36 months.

Warning: This toy has no brake.

Warning: Protective equipment should be worn. Not to be used in traffic.

PRODUCT SPECIFICATIONS

Battery	12V7AH*2
Drive Motor	24V 250W
Main material	PP
Suitable age	8-12 years old
Weight limit	65kg
Product size	130*55*79CM
Speed	250W motor: 8-16km/h
Runtime	40 minutes after charging 8-12 hours, based on ride on conditions
Charger	Input: 100V-240V 50/60Hz / Output:24V1.0A <i>Only use the supplied charger. Using a charger, which is not supplied by the manufacturer, can damage the product.</i>
Fuse	Auto-reset fuse

Assembly instruction

Car assembling should be done by the adults.


Take care of small parts. To avoid choking hazard, keep children away while assembling. Children under 36 months are prohibited to use.

Please count all the parts carefully before assembling and dispose the plastic bag properly. To avoid choking hazard, children are not allowed to play with the bag.

1. Fender assembly

Using the screwdriver, remove the M5*50 screw bolt and the M5 nut front the fender ②.

Insert the fender ② into front fork as shown in the picture, the front of the fender ② is longer, and the rear of the fender ② is shorter. Align the holes on fender ② with the fixing hole on the front fork, insert the screw bolt, using a screwdriver, securely fasten them with the nut.




2. Front wheel assembly

Attention: Using the adjustable wrench, remove the front axle (C). You will not need the front axle (C) for the next assembly steps.


Remove two black protective covers from the front wheel ③. You will not need the two black protective covers for the next assembly steps.

Using the adjustable wrench, loosen two nuts (A) from front wheel ③, then remove two washers (B). Place the front wheel ③ into the front fork as shown in the picture. Add the washer (B) on each side, insert the hook on the washer (B) into the hole on the front fork. Then secure the front wheel ③ by tightening two nuts (A) using the the adjustable wrench.




3. Handlebar assembly

Remove the protective cover from the metal tube on handlebar. Insert handlebar into metal tube on car body, insert all the cables into the car body. Using a screwdriver, loosen two screws from dashboard cover, then open the dashboard cover. Center the front wheel and handlebar, using the wrench ⑤, secure the fixing nut. Reattach the dashboard cover, using a screwdriver, secure two screws.





4. Battery connection

Before first using, match two red plugs to connect the power under the seat.



5.Seat assembly

Using the screwdriver, loosen the screw bolt and the nut from the car body, tilt the seat ④ and align the metal sheet with the corresponding openings on car body. Press down on the front of the seat ④, match the screw holes on the seat ④ and car body. Insert the screw bolt, using a cross screwdriver to fix it with the nut.






6. Brake adjustment method

(1) If there's too much travel on the brake, it needs tightening. Loosen the nut (d) on the brake lever in an anticlockwise direction to tighten the brake.

(2) After adjusting, there's still too much travel on the brake, the nut (e) near the brake disk needs adjusting. Loosen the nut (e) in an anticlockwise direction to tighten the brake.

(3) After adjusting, there's still too much travel on the brake, the nut of brake cable (f) needs adjusting. Loosen the nut of the brake cable (f) in an anticlockwise direction, tighten the brake cable and hold it on, rotate the wheel to check the degree of tightness. When you feel a little friction on the wheel, tighten the nut of the brake cable (f) in a clockwise direction.



SECURITY WARNING

1. The installation and charging of vehicle should be under adult supervision at all times.
2. Recommended only for children 8-12 years old. And do not exceed 65kg rider weight.
3. This product is ideal for driving on a hard flat surface.
4. It is strictly prohibited in the streets or the road, pot holes, and slopes.
5. Avoid driving in the sand or grass or uneven ground.
6. Children should be given full instructions on operation of the car. Improper operation can cause damage or accidents.
7. While children are driving, it is parents' duty to supervise at all time to avoid accidents.
8. Avoid driving in rains or flooded pathways. By doing so it can damage the motor, circuit and other electrical equipments.
9. Battery charger should be regularly inspected by parents to insure that the wires, plugs, crusts and other components are not damaged. Please stop using if any damage is found, until it is completely restored.
10. In order to ensure product life and safety, avoid damage to the charger, battery or electric circuit, the car must use the default configuration of a dedicated charger and power supply.
11. Rechargeable batteries should be removed from the toy before charging.
12. When no use of product, please cut off the product power, and keep all the switch to "stop" or "off" position.
13. The charger provided is not a toy. It is to be kept away from children.
14. Strictly prohibit using the non-manufacturer provided parts.



WARNING:

WARNING: This toy is unsuitable for children under 6 years due to its maximum speed.

WARNING: This toy produces flashes that may trigger epilepsy in sensitised individuals.

USAGE DIRECTION

1. Before using it, make sure that all the following works are done.

- Step described in accordance with the instructions to complete the installation of the car, the battery plug-in has been connected, the power supply has been switched on.
- Make sure that all the positions which need the screws are fixed tightly.
- Parents or guardian should ensure that children have taken the safety measures before using.

To reduce the risk during using, pay attention the followings: When driving the car ,child should sit on the car seat.

Adult or parents should take more care and guidance when child driving and can't leave away.

Pay attention to the driving environment and driving on the hard flat surface, not the unsafe environment.

For example:

- a.The trenches, the riverside, slope or uneven ground;
- b.Road or other places for driving and walking;
- c.The obstruction which is easily hitting and causing injury;
- d.Other unsafe zones.

To avoid accident, please use only in daytime or bright place, avoid using under low visibility.

FUSE

This car has a auto-reset fuse, if the car stops suddenly during driving, it is mainly caused by instantaneous current exceeds ,which makes the fuse to trip. Then just stop operating for about 8 seconds, and this fuse can be reset. Then turn on the power switch again.In order to avoid the fuse tripping and cutting off power supply, please pay attention to the following matters.


This product can't be overloaded, the maximum load is 65kg.

Don't drag anything behind the product.

Don't let the water or other liquid into the batteries and other electrical components.

Don't change the circuit system and structure of the product.

2. Operating(function reference diagram)




CHARGING WAY

For Safety purpose ,the charging must be done by adults.

Before first using, match two red plugs coming from two red cables under the seat, use it after charging 8-12 hours.

Charging port is located at the right side of the motorcycle. Please follow the instructions to charge the battery.

1. First insert the plug of the charger into the charging port. (The car can not be used during charging.)
2. Then insert the charger to the power socket.





WARNING:

1. The toy is to be assembled by an adult. In unassembled state, it contains potentially hazardous sharp points & small parts, so please keep out of baby's reach.
2. CHOCING HAZARD – Small parts. Not for children under 3 yrs.
3. Always wear shoes.
4. RISK OF FIRE. Do not bypass. Replace only with circuit protection device.
5. Protective equipment should be worn. Not to be used in traffic.

Attention:

- Can only use the charger and battery according to manufacturers regulations.
- Do not mix old and new or different types of batteries.
- The battery terminal should not be short circuit.
- Do not open the battery or charger.
- Do not reverse the battery.
- Before charging, please check whether the charger, battery and plug are ok, if you find any broken parts, you must stop using it immediately. And do not use it until it is fully repaired.
- The battery will be little warm when being charged, it is normal. If not, it may be caused from the short circuit of charger or circuit board.
- Must use the pressing plate to fix the battery.
- Run out of battery must be handled by adults, remove the battery which has run out from toys to recycle properly and shall not be arbitrarily discard.
- If the product is going to be stored unused long time , it must be fully charged, and charge it every 3 months ,so as to make sure the battery life.
- Charger and Battery are not toys. Keep them away from children.

MAINTENANCE AND SERVICE

1. Before use, parents should check whether all parts like batteries, charger, wires, plug, outer body and other parts are in good condition, check whether the screws are loose and whether there are potential safety hazards. Any damaged parts founded should be repaired before using.
2. After using the product for a period of time, use a small amount of lubricating oil to the moving parts to prevent wear and tear of rust.
3. Keep the car away from fire and direct sunlight. Place it stably, not upside down. The car shall be stored indoors or outdoors under cover.
4. The car should be kept away from hot items, such as stoves or heaters, or the plastic parts will melt. When charging, the car should be kept away from inflammable materials to prevent it from catching fire.
5. Charge in time after use. Charging should be done by adults. If the product is going to be unused for a long time, it must be fully charged. Charge it every month so as to extend the battery lifespan.
6. A soft cloth must be used to clean the car. Do not use chemical solvents to clean the plastic parts. Do not use soap or water to clean the car. Driving in rainy or snowy weather, water can damage the motor, battery and circuit system.
7. When stopping or storing the car, please cut off the power and make sure all switches are in the 'STOP' or 'OFF' position.
8. Do not use fuses different from the specifications of this product.
9. Do not change the product structure and circuit system. Maintenance and repair work must be done under the guidance of the professional or technical personnel in place.
10. Do not use the product for other purposes. Put the battery in the right polarity.
11. Battery negative short circuit is prohibited. Non-rechargeable batteries cannot be charged.
12. Rechargeable batteries can only be charged under the supervision of the adult.
13. Do not mix old and new batteries or different types of batteries.
14. The battery running out of power should be removed from the car properly and not allowed to be played by children.
15. Disconnect the batteries completely when not in use and do not allow children to play with them.

TROUBLESHOOTING

Motorcycle does not move or power on	If "power" switch is in OFF position
	If the fuse is not functioning properly
	If the battery is not connected, check the red and black wires.
	If the charger is plugged in, car will not power on. Unplug charger.
	If the throttle is not functioning properly
	If the wheels stuck and cannot move
Motorcycle moves slowly	If the battery is not fully charged. Need to be charged in time
	If there is an issue with the wheels
	If rider weight exceeds specifications
Battery does not charge	If the charger is malfunctioning
	If the battery lost its capacity
	If the charger and battery connection are charged

Battery Disposal



The battery will eventually lose the ability to hold a charge. Depending on the count of use and varying conditions, the battery should operate for one to three years.

Important! Recycle the dead battery responsibly. The battery contains lead (electrolyte) and must be disposed of properly and legally, it is illegal in most areas to incinerate lead acid batteries or dispose of them in land field, Please take it to your local approved recycling centre or a battery retailer for safe disposal.

Do not throw the battery away with your regular household waste!

WARNING:

This toy contains batteries that are non-replaceable.
A recommendation for adult supervision of young children.

WARNING:

To reduce risk of injury, adult supervision is required.
Never use in roadways, near motor vehicles, on or near steep inclines of steps, swimming pools or other bodies of water, always wear shoes, and never allow more 1 rider.
Only use the specified by the manufacturer battery.
Only use the charger specified by the manufacturer.



WARNING:

Assembly by an adult

Maximum capacity: 65kgs (143lbs)

- This toy contains batteries that are non-replaceable.
- Rechargeable batteries are only to be charged by adult.
- Instructions to be given to the child in the proper use of the toy, particularly in the use of any braking system
- A reminder that the toy should be used with caution since skill is required avoid falls or collisions causing injury to the user or third parties.
- Exhausted batteries are to be removed from the toy.

UK

If you have any questions, please contact our customer care center.
Our contact details are below:



0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS:
MH STAR UK LTD
Unit 27, Perivale Park,
Horsenden lane South
Perivale, UB6 7RH
MADE IN CHINA

