

Screen it

HOW TO APPLY STATIC CLING WINDOW FILM

CREATE
YOUR WORLD

we've got it covered!

Step 1



Tools for the job!

Step 2



Clean glass thoroughly to remove dirt or dust.

Step 3



Measure the glass.

Step 4



Use grid on backing paper to mark size.

Step 5



Cut the vinyl 2mm smaller than the window, this ensures the vinyl is not touching the edge or seal.

Step 6



Spray the glass with water and a few drops of washing up liquid.

Step 7



Peel away the backing paper.

Step 8



Apply onto the glass and slide the vinyl into place leaving a gap away from the edge. Use a d-c-fix smoother or squeegee to remove any excess water.

Step 9



Dry surface with a cloth, leave to dry completely (takes around 48 hours).

Follow us

