

## EcoFlow 800W Alternator Charger installation Guide

### Clean, easy install without leaving a mark

Connect your 800W Alternator Charger to your vehicle's starter battery or RV's house battery to enjoy a worry-free power experience during your journey.

**Step 1:** Connect the fuse cable to the input cable on one end.



**Step 2:** Connect the fuse cable to the vehicle battery on the other end.



**Step 3:** Connect the black cable to the chassis terminal.

**Step 4:** Thread the other end of the input cable through the car body towards the charger. If the input cable is bulky or difficult to pull through, disconnect the cable ends before threading.:



**Step 5:** Plug the other side of the input cable into the EcoFlow 800W Alternator Charger.



**Step 6:** Plug in the output cable from the EcoFlow 800W Alternator Charger to the portable power station.

