

Step 1

Measure the Length

If you have an existing toilet seat, remove it. Use a measuring tape to measure from the center of the bolt holes to the front edge of the bowl.



Step 2

Measure the Bolt Spread

With no toilet seat in place, use your measuring tape to measure from the center of the left bolt hole to the center of the right.



Step 3

Measure the Width

Measure the width of the toilet from lip to lip at the widest point. This can lead to some options fitting your toilet better than others.

For the best results, note this measurement and check the width of your toilet seat options before making a purchase.

