

STORMSURE

Fixes almost everything!



Repair Kits

*Contents of the repair kits may differ depending on the repair.



Stormsure Flexible Repair Adhesive

TUFF Tape



STORMSURE

Stormsure 'Flexible Repair Adhesive' is a very strong general purpose adhesive and it can also be used as a surface sealant.

Bonds to virtually all surfaces including neoprene, rubber, leather, PVC, polyurethane, breathable and coated fabrics, wood, metal and more. It is ideal for repairing cracks in rubber wellington boots, hiking boots, loose soles, leaks in waders, rips in wetsuits, damaged horse rugs, holes in tents and canopies, leaks and splits inflatable items and many other items too. It can also be used for repairs to woodwork and furniture, roof tiles and concrete.

USES: A tube of Stormsure Flexible Repair Adhesive is an essential part of a repair kit for hikers, DIY, fishermen, equestrians, hunters, divers, campers, surfers, sailors, engineers etc!

DIRECTIONS: Use the adhesive at room temperature. Clean the damaged area to remove dirt and grease (sandpaper the surface for best adhesion). Apply a generous amount of Stormsure Adhesive to the damaged area, with at least a 5mm extra around the damaged area. Leave horizontal and allow to cure for 10-12 hours.



TUFF TAPE

Stormsure 'TUFF Tape' is a very strong, clear, self-adhesive, waterproof tape that is sold as individual pre-cut patches and strips of various shapes and sizes. TUFF Tape is made of a thin, but very tough, polyurethane film with a pressure sensitive adhesive and backing paper on the rear side.

USES: Use TUFF Tape to quickly repair rips in waterproof clothing, ripped netting and fabrics, inflatable mattresses, canoes and RIBs, tents and awnings, sails and kites, waders, cracked buckets and other plastic containers, PVC curtain sides, inflatables, hot tubs and spas and many more.....

DIRECTIONS: Ensure that the surface is clean and dry before using. Cut a suitable sized piece of TUFF Tape for your repair using good quality scissors or a sharp scalpel blade. Peel off the backing paper. Carefully position and then apply the TUFF Tape directly on top of the damage. Start at one edge and press the tape down gradually to avoid the entrapment of air bubbles. Once the TUFF Tape is in place rub it firmly with a smooth and hard object (such as the back of a spoon) to ensure the maximum adhesion to the substrate.

Find your repair?

Scan here to find your repair in our Frequently Asked Questions Section:



Scan me

Visit: stormsure.com/howtofix

DISCLAIMER: Stormsure shall not be liable to the Product User for any pure economic loss, loss of profit, loss of business, depletion of goodwill or otherwise, in each case whether direct, indirect or consequential, or any claims (including in respect of personal injury insofar as not caused by the Company's negligence) for consequential compensation whatsoever (howsoever caused) which arise out of or in connection with the use made or resale by the Product User of any of the Products in the TDS.

Stormsure shall not be liable to the Product User in relation to any loss for any use which is inappropriate or use which is otherwise than in accordance with the relevant instructions for use of the Products in the data sheets or on the Product. Product Users are advised to confirm the suitability of the Products by their own tests.

