

SLATWALL MIDI FITTING GUIDE



Transforming your room has never been easier.
Create your dream wall with SlatWall Midi in hours,
not days, by following these simple steps.

WHAT YOU'LL NEED

- SlatWall Midi panels
- Tape measure
- Spirit level

YOU MAY ALSO NEED

- Pencil
- Square tool
- Fine-toothed hand saw
- Sharp utility knife
- Top Trim (sold separately)

INSTALLATION WITH SCREWS

- 9 (3.5mm x 35 mm) screws per panel
- Screwdriver
- 45mm battens (optional)
- 45mm mineral wool (optional)

INSTALLATION WITH ADHESIVE

- Hybrid Grab Adhesive
- Sealant gun

GET TO KNOW YOUR PANELS

- Panel size: 1200mm (H) x 600mm (W) x 21mm (D)
- Slat size: 27mm (W) x 12mm (D)
- Slats per panel: 15
- PET felt backing: 9mm (D)
- Single panel coverage: 0.72m²

PLAN AHEAD

1. Remove any screws, nails or other fixtures from your wall.
 2. Make sure your wall is clean, smooth and level.
 3. Unbox all your packages and check the panels.
 4. Decide on your layout.
 5. Measure your wall and mark your starting point using a spirit level and pencil.
 6. Cut the panels to size if needed.
-



MAKE THE CUT

1. Measure where you want to cut.
2. Mark a straight line with a square tool and pencil.
3. Cut the panel horizontally with a fine-toothed hand saw or cut the felt backing vertically with a sharp utility knife.

FORM A STRONG BOND

With screws:

1. Install your first panel by aligning the screws in rows of three and fixing it to your wall. Pick screws in a colour that coordinates with your felt backing and use the appropriate fixings for your wall (e.g. wall plugs). Top tip: make sure the outer screws are 50mm from the panel's edge and use a spirit level to check the panel is level.
2. For maximum (Class A) acoustic performance, install the panels onto 45mm (D) battens with 45mm mineral wool between each batten.
3. Repeat for each panel.

Important: if installing the panels on a ceiling, fix the screws to structural points such as joists.

With Hybrid Grab Adhesive:

1. Apply Hybrid Grab Adhesive approximately 20mm from the edges in three wavy lines on back of your first panel.
Top tip: one tube of adhesive covers 6 panels.
2. Position the panel against your wall and press firmly to secure it.
3. Repeat for each panel.

GIVE YOUR WALL AN EDGE

To give your half-wall panelling a classic finishing touch, we recommend using a coordinating Top Trim.

DO AS YOU SEE FIT

If adding fixtures and fittings, such as shelves or TV brackets, drill through the panel and sub wall, then use appropriate wall plugs and screws.

LAST BUT NOT LEAST

Stand back and marvel at your beautiful wall.

We're here to help with your wall transformation.

If you have any questions about installing SlatWall Midi, please contact our customer service team at info@naturewall.com.

