

SLATWALL MINI FITTING GUIDE



Transforming your room has never been easier.  
Create your dream wall with SlatWall Mini in hours,  
not days, by following these simple steps.

---

## WHAT YOU'LL NEED

- SlatWall panels
- Tape measure
- Spirit level

## YOU MAY ALSO NEED

- Pencil
- Square tool
- Fine-toothed hand saw
- Sharp utility knife
- Top Trims (sold separately)

## INSTALLATION WITH SCREWS

---

- 7 (3.5mm x 35 mm) screws per panel
- Screwdriver
- 45mm battens (optional)
- 45mm mineral wool (optional)

## INSTALLATION WITH ADHESIVE

---

- Hybrid Grab Adhesive
- Sealant gun

## GET TO KNOW YOUR PANELS

---

- Panel size: 600mm (H) x 600mm (W) x 21mm (D)
- Slat size: 27mm (W) x 12mm (D)
- Slats per panel: 15
- PET felt backing: 9mm (D)
- Single panel coverage: 0.36m<sup>2</sup>
- Four-pack panel coverage: 1.44m<sup>2</sup>

## PLAN AHEAD

---

1. Remove any screws, nails or other fixtures from your wall.
  2. Make sure your wall is clean, smooth and level.
  3. Unbox all your packages and check the panels.
  4. Rotate the panels in different directions to decide on your layout.
  5. Cut the panels to size if needed.
- 



## MAKE THE CUT

---

1. Measure where you want to cut.
2. Mark a straight line with a square tool and pencil.
3. Cut the panel horizontally with a fine-toothed hand saw or cut the felt backing vertically with a sharp utility knife.

## FORM A STRONG BOND

---

### With screws:

1. Install your first panel by aligning six screws in rows of three and fixing it to your wall. If you wish, you can also position a seventh screw in the centre of the panel. Pick screws in a colour that coordinates with your felt backing and use the appropriate fixings for your wall (e.g., wall plugs). Top tip: make sure the outer screws are 50mm from the panel's edge.
2. For maximum (Class A) acoustic performance, install the panels onto 45mm (D) battens with 45mm mineral wool between each batten.
3. Repeat for each panel.

Important: if installing the panels on a ceiling, fix the screws to structural points such as joists.

### With Hybrid Grab Adhesive:

1. Following the square shape, apply Hybrid Grab Adhesive approximately 20mm from the edges, along with an 'X' formation on back of your first panel. Top tip: one tube of adhesive covers 12 panels.
2. Position the panel against your wall and press firmly to secure it.
3. Repeat for each panel.

## GIVE YOUR WALL AN EDGE

---

To give your half-wall panelling a classic finishing touch, we recommend using a coordinating Top Trim, available in Natural Oak and Walnut.

## DO AS YOU SEE FIT

---

If adding fixtures and fittings, such as shelves or TV brackets, drill through the panel and sub wall, then use appropriate wall plugs and screws.

## LAST BUT NOT LEAST

---

**Stand back and marvel at your beautiful wall.**

We're here to help with your wall transformation.

If you have any questions about installing SlatWall Mini, please contact our customer service team at [info@naturewall.com](mailto:info@naturewall.com).

