

Installation Instructions

High-Pressure Chrome Shower Head with 1.5 m Hose (Universal Fit)

What's Included

- 1 x High-pressure shower head
- 1 x 1.5 m flexible hose

Installation Steps

1. Turn off the water supply.
2. Remove the existing shower head by turning it anti-clockwise.
3. Attach one end of the hose to the shower outlet and hand-tighten.
4. Attach the shower head to the other end of the hose and hand-tighten.
5. Turn on the water and check for leaks.

Care & Maintenance

- Clean regularly with a soft cloth.
- Rub nozzles gently to remove limescale.
- Do not use abrasive cleaners.

Important Information

- Universal G $\frac{1}{2}$ " connection
- Tool-free installation
- Suitable for high and low-pressure systems