

STEP 1

Measure and mark where you want to attach the screen on the brick wall, using a tape measure and pencil or chalk as this can be easily removed. Exact measurements will depend on the size of your screen. Mark a line on the wall and use a spirit level to ensure that the line is straight and plumb.

STEP 2

Mark on the screen where a suitable hole can be drilled, Care should be taken not to drill a hole too close to an edge. A 4mm hole no closer than 15mm from any edge

Where the pattern includes a hole close to the corners, other areas of the screen can also be considered.

Hold the screen against the wall using the chalk or pencil marks made in the first proces.

Mark though the holes in the screen and drill the wall to fit Rawplug 8mm hole recommended

Mark though the holes in the screen and drill the wall to fit Rawplug

Please also note that the screens can be installed to 'stand off the wall' if required, in this instance we would suggest a 16mm PEX Pipe which can be cut to size to achieve the desired look.

STEP 3

Stand back and admire your decorative garden screens!