



Cre8 Tongue & Groove MDF Panels Installation Guide

FOLLOW THE INSTRUCTIONS IF YOUR WALLS ARE FLAT:

- Prime the surface beforehand to ensure a better connection. The surface must be perfectly flat.
- Make vertical markings on the wall to place the 1st panel. If necessary, the panel can be cut to the desired size
- Apply MCW PU Adhesive to the back of the panel and attach to the wall.
- PU Adhesive can be applied to the back of panel No.1 according to the recommended scheme. Hold the panel in place with force to distribute the adhesive evenly.
- Apply MCW PU Adhesive to the back of panel No. 2 as with panel No. 1
- Panel No.2 should be inserted into the groove of Panel No.1
- When installing the panels, it is recommended to use Horizon 2D Corner Trim to match the colour of the panels

FOLLOW THE INSTRUCTIONS IF YOUR WALLS ARE UNEVEN (IF THE SURFACE IS UNEVEN, MAKE A CRATE)

- Attach wooden battens to the wall that will act as a support rail with suitable nails or with PU Adhesive to create a frame/structure to attach the panels to.
- To avoid unevenness of the wall surface, set the correct level with wooden wedges.
- Place the panel on the battens using Horizon 2D Clips (sold separately)
- Use nails to fasten it with Panel Clips on the groove side. Use this method for all panels.

Please refer to the image on the last page.





Cre8 Tongue & Groove MDF Panels Installation Guide

