

# ROOFER'S NO. 1 SHED KIT INSTRUCTIONS

ROOFER'S  
NO.1



## STEP 1

Remove the existing roof covering and check that the deck is dry, clean, and free from rot.



## STEP 2

Position the rubber membrane on the roof and allow it to relax for at least 20 minutes. Then fold it back to the centre of the roof to expose half of the deck



## STEP 3

Apply a thin layer of water-based adhesive to the exposed deck using a roller. While the adhesive is still wet, roll the membrane into place and smooth out any air bubbles with a soft brush.



## STEP 4

Apply a bead of sealant onto the membrane around the perimeter. While wet, fix the original wood trim onto the membrane to terminate



## STEP 5

Trim away any excess rubber and dispose of it. Your installation is now complete.