

Woodeedoo Clear Floor Varnish

(Matt / Gloss Finish)

Surface Preparation

- Sand back to **bare wood** (finish with 220–240 grit).
- Ensure surface is **clean, dry, and dust-free**.
- Remove old varnish, paint, or wax before application.

Application

- Shake bottle well – do not dilute.
- Apply thin, even coats with **brush or roller** along the grain.
- Wipe excess with a clean lint-free cloth.

Coating Process

- Apply **minimum 2 coats**, recommended 3.
- Lightly sand (220–240 grit) between coats for best adhesion.
- Coverage: **10–12 m²/L (first coat), 15–18 m²/L (subsequent coats)**.

Drying & Curing

- Touch dry in ~20 minutes.
- Recoat after **2 hours**.
- Full cure in **3–5 days** (avoid heavy use until then).

Safety

- Indoor use only.
- Keep out of reach of children & pets.
- Do not swallow.
- Avoid contact with skin and eyes.

Storage & Disposal

- Store in sealed container at **+5 °C to +25 °C**.
- Protect from frost & direct sunlight.
- Dispose of leftovers and empty bottles at local recycling facilities.