

Woodeedoo Wood Varnish | Clear

(Matt / Satin / Gloss)

Application Instructions

1. Surface Preparation

- Ensure the wood is **dry, clean, and free from dust**.
 - The varnish can be applied to **bare wood or stained wood**.
 - Do **not** apply over lacquered, painted, or previously varnished surfaces.
 - Remove any traces of wax or grease before starting.
 - Lightly sand the surface with **220–240 grit** to ensure good adhesion.
-

2. First Coat

- Shake bottle well – do not dilute.
 - Apply a **thin, even coat** with brush or roller, following the grain.
 - Allow to dry for about **20 minutes**.
-

3. Sanding Between Coats (Required)

- Once the first coat is dry, **lightly sand with 220–240 grit sandpaper**.
 - This step is essential for adhesion and a smooth finish.
 - Remove sanding dust with a lint-free cloth.
-

4. Second Coat

- Apply the second **thin, even coat**.
 - Allow to dry for at least **2 hours**.
 - This provides full protection for most interior wood applications.
-

Key Notes

- Coverage: **10–12 m²/L (first coat), 15–18 m²/L (second coat)**.
- **Minimum 2 coats required**.
- Apply only between **+5 °C and +25 °C**.

- Indoor use only.
- Full curing time: **3–5 days**.