



Product Instruction Manual

3mm Silver Wood Flooring & Laminate Underlay (1m x 15m Roll)

Installation Instructions

1. Ensure the subfloor is clean, dry, smooth, and level before installation.
2. Roll out the underlay with the foil side facing upward unless advised otherwise by the flooring manufacturer.
3. Lay the underlay edge-to-edge without overlapping sections.
4. Secure and seal joins using suitable foil tape to maintain the damp proof barrier.
5. Install laminate or wood flooring using a floating floor fitting system.
6. Trim excess material neatly using a utility knife.

Care & Storage

- Store indoors in a dry environment.
- Avoid prolonged exposure to direct sunlight or excessive moisture.
- Keep packaging away from children and pets.
- Dispose of packaging responsibly after use.

Safety Information

- Keep away from open flames and heat sources.
- Use cutting tools carefully during installation.
- Follow flooring manufacturer recommendations at all times.

Package Contents

1 x 3mm Silver Wood Flooring & Laminate Underlay Roll (1m x 15m)