



BOSCH

Invented for life

More power in your hands.

With the **EasyPrune** cordless secateurs.



Home made by you.

[bosch-garden.com](https://www.bosch-garden.com)

EasyPrune

A cut above the rest

The **EasyPrune** cordless secateurs are perfect for everyday gardening tasks. Whether you're pruning flowers, trimming hedges or cutting back shrubs – the **EasyPrune** with stainless steel blades lets you cut off branches up to 25 millimetres in diameter with ease.

Cut not crushed:
The bypass cutting system creates a clean cut every time. And the ergonomic design of the secateurs makes them remarkably simple and straightforward to use.

The **EasyPrune** cordless secateurs are lightweight and sit comfortably in the hand. Thanks to innovative, electronic Power Assist Technology, you can work for longer no matter how many cuts you make.

490 grams

Up to
450 cuts
per battery charge

Up to
25 mm
cut diameter



Power assisted cutting

Power in your hands

New Power Assist Technology makes gardening by hand easier than ever before. Simply squeeze the handles together and the **EasyPrune** helps you by supplying more force. When you cut a thick branch or a higher resistance is detected, the power assistance function activates automatically. If the cutting process is stopped, it switches itself off again. You have full control at all times.

Set the power assistance level to suit the work you're doing, i.e. according to the material you're cutting and how thick it is. There are three levels to choose from – low, medium and high.



Cut through branches up to 25 millimetres in diameter quickly, effortlessly, and with just one hand.

High	95% support*
Medium	85% support*
Low	75% support*


* With a maximum diameter of 25 mm

1. Depending on the type of material you're cutting and how thick it is, cutting a branch the conventional way can require a lot of force.

2. When the pressure being exerted on the EasyPrune exceeds a certain level, the electronic power assist function is automatically activated; this is called Power Assist Technology.

3. **What happens:** Power Assist Technology identifies when additional force is required to make the cut with ease. The motor starts helping the upper and lower handles move towards each other, assisting the cut.

4. Once the cut is completed, the Power Assist Technology automatically resets.





Clean cut

The **EasyPrune** uses a bypass cutting system, whereby the two premium-quality stainless steel blades glide past one another. This enables you to cut branches without having to stop or keep repositioning the secateurs in the process. A clean cut helps to promote healthy tree growth.



USB charging function

The battery charge level indicator shows you how charging is progressing and how much battery power the cordless secateurs have left when you are using them. You can charge your **EasyPrune** using the Bosch micro USB charger supplied.



Changeable blade

The two blades on the **EasyPrune** are made of premium-quality stainless steel, which allows for clean, even, tear-free cutting. If needed, the upper blade can be replaced in no time at all. Simply use a hexagon socket spanner to unscrew the old blade, take it out, put a new blade in and retighten the screw. Done!



Up to 450 cuts

With a full battery, the **EasyPrune** can cut up to 450 times with electronic assistance before it needs charging again. You can also alter the Power Assist level to suit your needs. The power is in your hands.



BOSCH

Invented for life



bosch-garden.com

Robert Bosch Ltd.

Broadwater Park
North Orbital Road
Denham
UB9 5HJ
England

1619 XXXXX – INT – Printed in Federal Republic of Germany –
Subject to technical alterations. No liability can be accepted for printing errors.