

Surface Mounted Coax TV/Radio Aerial Splitter


19123QR

User Guide

Installation Instructions

The splitter can be used to split the signal from an FM or DAB radio aerial or TV aerial.

- Strip 24mm of the outer sheath from the aerial downlead, pull back braid and tear off or cut off foil if present.
- Twist braid together and wrap around inner insulation as shown, strip 12mm from inner insulation to expose central conductor.
- 3. Loosen terminal and saddle clamp screws and insert cable as shown in Fig. 3. Tighten all screws and trim away any loose strands of braid.





Customer Careline: 08457 573 479

(Local Rate - UK Only)

Technical Support:

www.slxtechnology.com/support



UK Distributor: Philex Electronic Ltd, Philex House, London Road.

Bedford, MK42 0NX, UK.

© Philex Electronic Ltd. 2021. vb1.1