

EN Outdoor Silhouettes



EN IMPORTANT - These instructions are for your safety. Please read through them thoroughly prior to handling the product and retain them for future reference.

V10324_5059340992266_MAND2_2324

5059340992266

EN Parts




01. x1



02. x2



03. x4



04. x1

EN Contents

EN	
Use	3
Functions & Settings	4
Troubleshooting	5
Assembly	6



EN Use


EN

Before you start








- Decide on an appropriate location for your product (see siting instructions below).
- If you are in any doubt about installing this product, consult a qualified electrician.
- Check the pack to make sure you have all of the parts listed.
- Ensure that the cables are fully unwound before use.
- Check the set before use for loose or damaged wiring and that all the bulbs are secure. If you are in doubt do not use the set.

Siting instructions

- This product is suitable for indoor or outdoor use.
- Plug the transformer into the mains socket ensuring the unit is positioned so that you have enough cable to reach an indoor mains power socket.
- The transformer must be located indoors.
- This product is suitable for positioning on surfaces which have normal flammability, e.g. wood, plasterboard or masonry. However, this does not include highly flammable surfaces (e.g. polystyrene or textiles).
- Always position cables and extension leads so that they will not be a hazard to the elderly, pets or children.
- DO NOT position or allow any part of the set to come into contact with a source of heat or flame.
- DO NOT position this set where it may become covered by other items e.g. curtains, nets or bedding.
- This product is not designed for permanent or long term use. Always switch off the light chain overnight or if unattended. Do not overload power sockets of extension leads.
- DO NOT cover ventilation holes on the base.
- Non-replaceable control gear.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- Do not use or inflate in extreme weather conditions and remove water, snow or any obstacles before inflating.



Technical Data

	This product complies with conformity requirements of the applicable European Regulations or Directives.
	This product complies with conformity requirements of the applicable UK Regulations.
IP44	Splash-proof.
	Class II product - Double Insulated - No earth required.
	Class III product - designed to be supplied from a SELV (Separated or Safety Extra-Low Voltage) power source.
	Transformer must be located indoors only.
	Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or local store for recycling advice.
	Do not use with a dimmer switch.
xxWyy:	xx-year; yy-week of the year.

EN Functions & Settings



(UK)

- EN** To set and reset the timer, press Button: 6 hours on / 18 hours off.
Green light on = Timer is on

EN Troubleshooting

If the light chain fails to light, please check the following:

- Disconnect the set from the mains.
- Check that the jack plug on the light chain is connected to the transformer.



WARNING:

- DO NOT connect the light chain directly to the mains. Use only with the supplied transformer.
- DO NOT connect this light chain electronically to another light chain.
- DO NOT connect this light chain to a power supply while it is in the packaging.
- The light source of this luminaire is not replaceable: when the light source reaches its end of life the whole luminaire shall be replaced. DO NOT attempt to replace the non-replaceable bulbs in this light chain.
- Take care not to damage the cable or fittings.
- The external flexible cable or cord of this luminaire cannot be replaced. If part of the light set of the cord is damaged, the luminaire MUST be destroyed.
- This product is for use as a decoration only. Not to be used by children as a toy. Keep out of reach of small children.
- Please refer to the packaging or product rating label for product class, specifications and rating.
- DO NOT pierce the cable when securing in place, bend or stand on the light chain, as this will damage the bulbs or wiring.
- This product has a long cord, which may pose a strangulation hazard.
- DO NOT use or attach electric lights/light strings of any type to the inflatable.
- This is an electric product, not a toy. To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.

EN Assembly


01



01. x1



04. x1



02




02. x2




03. x4



03



02



Manufacturer:

UK Manufacturer:

Kingfisher International Products Limited,
1 Paddington Square, London, W2 1GG,
United Kingdom

EU Manufacturer:

Kingfisher International Products B.V.,
Rapenburgerstraat 175E,
1011 VM Amsterdam,
The Netherlands

EN www.diy.com

www.screwfix.com

www.screwfix.ie

**To view instruction manuals online,
visit www.kingfisher.com/products**

Made in China