

IMPORTANT: PRODUCT RECALL NOTICE

Cooke & Lewis Lesina mirrored cabinet


Procedure to remove Lesina cabinet item

5397007165494

1. Secure the mirror to each door using a suitable adhesive tape. Wrap around the top & bottom of each door.




2. Using an appropriate screwdriver, carefully remove each door by loosening the hinges (A) and carefully lifting away from the cabinet (B). Store the mirror doors in a safe place.



3. With care and support of another person if required, remove the securing screws (C) from the back panel of the cabinet taking care to support the cabinet whilst doing so.

Remove the cabinet from the wall and return with the doors to a local B&Q store for a full refund.



If you would like more information, please call our Customer Services Helpline

UK: 0300 303 4482 / ROI: 1800 946 327**

**Monday to Friday 8.30am–8pm, Saturday 9am–5pm and Sunday 10am–4pm