


www.kidsaw.co.uk

**KIDSAW**<sup>®</sup>

INSTRUCTIONS

MAKES FURNITURE CHILDS' PLAY




**1580W  
CHANGING UNIT  
4 DRAWERS**

IMPORTANT  
KEEP FOR FUTURE REFERENCE & READ CAREFULLY

**PARTS**


NO.	QTY.	LINEDRAWING
(A)	20	7x50mm
(B)	28	
(C)	28	
(D)	4	8x40mm
(E)	8	
(F)	6	
(G)	40	3.5x14
(H)	16	3.5x35mm
(I)	38	
(J)	28	
(K)	4	
(L)	1	
(M)	12	3x14
(N)	2	

# PARTS LIST




NO.	QTY.	NO.	QTY.
①	1	⑩	1
②	1	⑪	1
③	1	⑫	2
④	1	⑬	1
⑤	1	⑭	4
⑥	1	⑮	4
⑦	1	⑯	4
⑧	2	⑰	4
⑨	1	⑱	4
		⑲	4


1




2




3




4




5




6




7




8




9




10




11




12




13



14




15




4X

16



4X

17



18

