



# VERTICAL RADIATOR

# PRIOR TO INSTALLATION

Check that all of the parts are enclosed as per the contents table.


Ensure that the radiator is positioned so that it can be easily connected to the central heating system.

- Select a desired position for the radiator - ensure that the wall is strong enough to support the weight.
- Mark out where the brackets need to be positioned - check that the top and bottom pair are level.
- Drill hole and insert rawl plug into it.
- Insert the screw through the washer then the bracket and into the rawl plug.
- Repeat this for all 4 brackets.
- Insert the air vent and the end plug into the top two threads on the radiator.
- Hang radiator on brackets and plumb into your central heating.
- Bleed out any air bubbles once plumbed in using the air vent plug.

# COMPONENTS




Radiator (x1)



Bracket (x4)



Washer (x4)



Fixing Screw (x8)



Air Vent (x1)




End Plug (x1)

# INSTALLATION

SINGLE



DOUBLE



## **Living and Home**

### **A Home is for Living in**

For comfort and style update your living space.

Browse contemporary and classic designs and find the perfect home to your look and the perfect spot to lounge.

Put your feet up and sink into our stylish home decor.

We are mainly engaged in home, outdoor, home appliances, office, bathroom, provided high quality and affordable products for you. We value every one of our customers and our professional service team is always available to help you.

[livingandhome.co.uk](http://livingandhome.co.uk)