


## ***LED Tube Light (Installation Instructions)***

- LED Tube lights **do not** require the starter switch **or** ballast transformer used by a fluorescent lamp.
- Turn **OFF** electricity supply to the light.
- Remove the starter switch.
- You then need to determine whether you have an electronic or magnetic ballast.



### **Magnetic**



### **Electronic**



- If the ballast is magnetic the existing wiring can be left.
- If electronic:
  1. Establish which is the live supply to the ballast.
  2. Disconnect live to the ballast transformer and connect this live supply to one end of the tube, use existing wires where possible.
  3. Establish incoming neutral to the fitting and connect to opposite end of the tube (neutral may already be connected).
- Your LED tube is now ready for mounting and turning on.

**Enjoy your energy savings....**

Any electrical work should be carried out by a UK qualified electrician – warranty is only valid if installed by UK qualified electrician you may be required to supply copies of electrician's certificate