



Einhell

EXPERT



Cordless Chain Saw

GE-LC 18/25 Li Kit (1x3,0Ah)

Item No.: 4501760

Ident No.: 21030

Bar Code: 4006825608335

The Einhell cordless GE-LC 18/25 Li Chainsaw Kit combines the outstanding performance of an Einhell product with a high-quality OREGON guide bar and chain. Kickback protection with an instant-reaction mechanical chain brake and a stop claw keep you safe while you are working with the chainsaw. The rugged metal stop claw keeps the saw stable while you are working, and the ergonomic handle gives you a comfortable grip on the chainsaw. No tools are needed to adjust the chain tension or replace the chain. A big filler opening of the automatic chain lubrication system makes it easy to top it up if necessary. The set includes a fast charger and battery which can be used for all Power X-Change family products.

Features & Benefits

- Battery system - Power X-Change
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- System high-speed charger included
- High-quality chain and bar from OREGON
- Toolless chain tensioning and changing
- Ergonomic handle
- Sturdy stop claws made of metal
- Kickback protection with mechanical instant chain brake
- Big filler opening
- Automatic chain lubrication
- Chain catch bolt








Technical Data

- Accumulator	18 V 3000 mAh Li-Ion
- Charging time	1h
- Sword length	250 mm
- Max. cutting length	23 cm
- Chain cutting speed	4.5 m/s
- Oil tank capacity	200 mL
- Number of accumulators	1 Pieces

Logistic Data

- Product weight (kg)	2.97 kg
- Gross weight (kg)	4.97 kg
- Dimensions single packaging	225 x 480 x 245 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	21.4 kg
- Dimensions Export Carton	500 x 380 x 515 mm
- Container quantity (20"/40"/40"HC)	1088 2208 2760



Available as special accessories



Ersatzschwert 25cm 1,1
Chain Saw Accessory
Item No.: 4501753
Bar Code: 4006825607017
Einhell Accessory



Ersatzkette 25cm 1,1 40T 3/8
Chain Saw Accessory
Item No.: 4501754
Bar Code: 4006825607024
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory

Battery-Running-Times

One Battery for All	 sawing ¹ (pieces)
1.5 Ah	50
2.0 Ah	70
2.5 Ah	85
3.0 Ah	100
4.0 Ah	130
5.2 Ah	180
6.0 Ah	200

For best performance select a battery with at least 2.5 Ah

Test setup:

1) scantling 70x70 mm