



BEAM CLAMPS





48344 - BC1000
48346 - BC2000
48347 - BC3000
48348 - BC5000

OPERATION AND USE

Note: For details of our full range of accessories and consumables, please visit drapertools.com

Stock No.	Safe Working Load	Girder Beam Width A	Girder Beam Width B	Steel Plate Width C
48344	1000kg	75mm	220mm	4.8mm
48346	2000kg	75mm	220mm	5.5mm
48347	3000kg	80mm	320mm	7.5mm
48348	5000kg	80mm	320mm	9.5mm



SAFETY INSTRUCTIONS

Always ensure that the load to be slung does not exceed the rated capacity of the equipment being used. Also ensure that the structure to which the trolley or winch is attached meets or exceeds the safety parameters which are specified by the HSE. Do not allow the load to swing during operation and do not subject winches, pulleys, beam clamps and straps to shock loads.