

VALIANT STOVE THERMOMETER

Designed to provide important information for monitoring stove temperature and performance.

- Ideally place on the flue pipe just as it exits the stove, or high up on the stove side towards the front or simply lay flat on the stove top.
- Can be used to measure the temperature of the flue pipe or stove.
- Reduce or optimise fuel consumption.
- Optimise the stove temperature and reduce soot and carbon in the chimney.
- Decrease the risk of damage caused by running the stove too hot.

Safety Measures: • Never touch the thermometer when the stove is hot • Very high temperatures may temporarily decrease the strength of the magnet and in extreme circumstances cause the thermometer to fall off • Not suitable for stainless steel, or twin wall insulated flue pipes • Retain packaging instructions for reference.



Also use
with any steel or
iron patio heater,
bbq, range or
chiminea.

www.simplyvaliant.co.uk

The Accessory Outlet Ltd. Solution House,
Sandon Road, Therfield, Hertfordshire, SG8 9RE