



Angled Manual Valves




 Style may vary

Installation Guide

Other Information




Valve installation advice:

Please ensure that your radiator valves are fitted as per the below diagrams ensuring that a bleed point always remains at the top of the unit.





For further information on installing your radiator valves, please consult the instructions provided with them.

Tools required for installing:




Installation


Parts included:




1




2





3




4




5




6



7



8



9

