



NOTICE: READ CAREFULLY BEFORE OPERATING AND SAVE THESE INSTRUCTIONS.

WARNING:

1. Unplug or disconnect the appliance from the power supply before using and servicing.
2. If the supply cord is damaged, it must be replaced by a qualified person in order to avoid a hazard.
3. Use for short periods of time only. Inflate for a maximum of 5 minutes and deflate for a maximum of 5 minutes. Leave 5 minutes between each interval.
4. The air vent on the cover should be kept free of debris during use.
5. The airbed must be stored in a dry location.
6. After use, airbeds may require additional air to increase firmness. Add air to proper firmness.
7. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

NOTE: This product is not intended for commercial use.

NOTE: Drawings for illustration purpose only. May not reflect actual product. Not to scale.

CAUTION: TO AVOID THE RISK OF ELECTRIC SHOCK, DO NOT EXPOSE TO WATER OR RAIN.

WARNING! USE ONLY UNDER COMPETENT AND ADULT SUPERVISION.

THIS ITEM IS NOT A TOY. NEVER LEAVE CHILDREN UNATTENDED WITH THIS PRODUCT.

THIS IS NOT A BUOYANCY AID. DO NOT USE IN WATER.

KEEP AWAY FROM FIRE AND FLAMES.

AVOID PROLONGED EXPOSURE TO THE SUN.

DO NOT PLACE ON SHARP OBJECTS.

DO NOT OVER INFLATE. DO NOT USE A HIGH PRESSURE PUMP.

REPAIRING:

1. Completely deflate the airbed.
2. Clean and dry the damaged area.
3. Using pressure, apply the self-adhesive repair patch included and smooth out any air bubbles.

PLEASE NOTE: Sizes are approximate and may vary due to temperature and changes in air pressure. An increase in air pressure causes the PVC to stretch during the day which then may contract at night as the pressure drops. The airbed is not leaking, but you may wish to add more air to reach your desired firmness. This will become more stable after the first few uses.

CLEANING & STORAGE

Store in a clean and dry place.

Wipe clean with a mild detergent and clean water, do not use abrasive cleaners or strong chemicals.

Allow to dry fully before packing away.

Do not place on sharp or heavy objects near or on top of the mattress, which may cause damage.

PUMP DISPOSAL:


Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

DUAL FUNCTION: INFLATION & DEFLATION
EXCLUSIVELY DESIGNED FOR AIR BEDS


FOR FOAM TOPPED AIRBEDS ONLY:

1. Remove the white cap and plug from the port on the foam section of the airbed.
2. Inflate the bed with the built-in electric pump following the main instructions below.
3. Place the white plug back into the port on top of the airbed and screw on the plastic cover.



INFLATION


1.1




1.2




1.3




1.4



1.5




1.6




INFLATION WITH HAND PUMP(not included)

2.1




2.2



2.3




2.4




DEFLATION


3.1




3.2




3.3



3.4



3.5



MANUAL-DEFLATION

