



Sama Cascading Oil Jars Fountain


1. Place feature on a level surface at desired location.
2. Connect the hose to the pump's outlet nozzle and place at pump within the features cavity at its base.
3. Attach panel and ensure the pump's cable is feed through the gap in the panel as indicated.
4. Fill the reservoir with clean water and ensure that the pump is fully submerged when working.
5. Plug in and turn on. Wait for all trapped air to work its way out of pump system for water to flow.



1-3



2-3



3-3