

IBIZA 1 PERSON HAMMOCK

Product Instructions

Product No. 2522106.1

vonhaus


Let's get started!

Visit our product hub for useful tips and tricks on getting the most out of your new product.

SCAN ME



Assembly



You will need to find 2 fixed points from which to hang your Hammock. Try trees, thick beams or posts on your veranda (if suitable).

Your Hammock should hang in any space of 3 metres or greater. This should leave the centre of the Hammock around 20-30cm off the ground when you sit in it.

WARNING! Never hang your Hammock from a free-standing brick wall.



150 kg
Capacity




30 Mins

Need further help?
support@vonhaus.com

See our full range at
www.vonhaus.com


Assembly



Often the distance between the 2 fixed points will be greater than 3 metres and you may need some rope.

In this case, it is important to attach one or both ends to a higher point to give the Hammock some shape, roughly 90cm higher for each extra metre of span.

Assembly



Stretching the Hammock flat (as illustrated above) is not comfortable and may cause the Hammock to break.

The easiest way to determine where to hang your Hammock is by holding the Hammock in place before attaching any fixings. 2 people will be required to help with this step.

Information



150 kg



Do not tumble dry



Do not iron



Flammable materials



Do not wring dry

Information

Important Safety Notice

This product is **not suitable for use by children** or by individuals with **physical, sensory, or mental impairments** that may limit their ability to operate the equipment safely, **unless** they have been given supervision or instruction concerning the safe use of the product by a person responsible for their safety.

Improper use may result in serious injury. Always ensure the operator is capable of understanding and following all safety instructions provided in this manual.

When using this product, important safety rules must be followed. For your own safety, and for the safety of others, please read these instructions carefully.

WARNING! This Hammock is for outdoor use only. **DO NOT** use indoors.

WARNING! This Hammock is not designed or intended for use by children. Children should be supervised at all times as risk of entanglement and choking is present.

Assembly Information

CAUTION: The assembly pack contains small parts which pose a choking hazard to children and animals. Keep children and pets clear at all times during assembly.

Locate the Hammock in a suitable area where it will not create an obstruction.

Keep well away from sources of heat (such as fire), damp, or moisture.

DO NOT attach to awnings, parasols or gazebos.

WARNING! Do not exceed the maximum weight capacity of 110kg.

Do not use the Hammock with more than the recommended safe capacity, or if any parts appear to be worn or damaged.

Keep away from sharp objects, jewellery or clothing.

Take care with anything that will catch on the strings such as buttons or studs.

This product is not a swing. Children must be supervised at all times to ensure they do not play with the Hammock.

Do not jump into, or swing from or within, the Hammock. Never spin, twist or rotate the Hammock when in use.

Storage & Maintenance

Tie a few loose knots in the end of the strings at each end.

Hand Wash only.

Remove your Hammock immediately after the spin

cycle as dyes in the fabric may bleed.

CAUTION: Do not tumble-dry. Always hang your Hammock out to dry.

Store in a cool, dry place when not in use.

Always keep your Hammock indoors when not in use.

CAUTION: Never store your Hammock whilst damp.

Do not leave the Hammock outdoors in the rain, or expose to direct sunlight. This will cause the fabric and colour to deteriorate, reducing the lifespan of the Hammock. Please check your Hammock safety capacity each and every time prior to using.

If you are missing any components, contact our customer services department at support@vonhaus.com

DO NOT proceed with assembly if any components are missing.

Information

Customer Service

If you are having difficulty using this product and require support, please contact support@vonhaus.com

Warranty

To register your product and find out if you qualify for a free extended warranty please go to www.vonhaus.com/warranty

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately.

Any abuse of the product or the manner in which it is used will invalidate the warranty.

Returns

Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

Copyright

All material in this instruction manual are copyrighted by DOMU Brands.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.

Thank You

Thank you for purchasing your product/appliance.

Should you require assistance with your purchase, please contact us at support@vonhaus.com

Vonhaus is a registered trademark of DOMU Brands Ltd.

Made in China for DOMU Brands Ltd.
Unit 30, Stakehill Industrial Estate
Middleton, Manchester, M24 2RW

EU Authorised Representative

Authorised Representative Service
77 Camden Street Lower
Dublin, D02 XE80
Ireland

Let's get started!

Visit our product hub for useful tips and tricks on getting the most out of your new product.

SCAN ME

