


# Jack Stonehouse



## Portable Heater

WARNING: Please read this manual carefully before use

Codes:  
Y36-WHITE  
Y36-GREY

### SAFETY PRECAUTION

#### WARNINGS:


- In order to avoid overheating do not cover this product when in use
- Before use, please ensure power supply meets the requirements of this product and confirm the rated current of the socket is great than 5A.
- Do not use for extended periods of time.
- Keep out of reach of children or pets
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance providing that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
- CAUTION - some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- Children shall not play with this appliance.
- Cleaning and user maintenance shall not be made by children without supervision.

### SAFETY PRECAUTION

#### WARNINGS:

- Do not disassemble this product
- Keep away from fire
- Do not use in flammable, explosive, dusty, oily or humid environments
- This product should be used on a stable, flat surface at least 50cm away from obstruction
- Do not use near combustible items such as curtains, beds etc
- Not for outdoor use
- Do not touch the front vent when in use to avoid burns
- Do not touch the power switch or unplug the power cord with wet hands to prevent electric shock
- If power cord becomes damaged, stop use immediately and replace
- Do not place directly underneath the power socket
- During use of this product, if there is any abnormality, please stop use immediately.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge is they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool

### FUNCTIONS & CLEANING



- Before cleaning this product please unplug the power and wait for the unit to cool down before proceeding.
- Regularly clean the air inlet and outlet using a clean, dry cloth.
- When not in use please switch off power switch and unplug

### INSTRUCTIONS

#### Heating Function

1. Press the main power switch on the back of the unit, the small red light will illuminate on top of the unit and the heater will now be in standby mode
2. Press the heater switch (fan logo) on top of the unit, the red light will switch off and the first white light will illuminate. The heater is now on level 1 (approx 600W) of 3.
3. Press the heater switch a second time to toggle into level 2 (approx 900W) and three times for level 3 (approx 1000W).
4. Press the heater switch a fourth time to toggle back to level 1, the white light will flash and the heater will return to standby mode after 1 minute.

#### Lighting Function

1. Press the light button once to turn on the night light
2. Press the light button again to turn off

#### Safety Features

If the heater tilts more than 45 degrees it will automatically shut off and the red light will flash. When returned to a level position the red light will remain on and the heater will not switch back on until you press the heater switch.  
To help prevent overheating this product will automatically switch off after 12 hours in use.

If you have any questions please contact us on [sales@jackstonehouse.com](mailto:sales@jackstonehouse.com) or 01604 537900

### PRODUCT PARAMETERS

Product model: Y36

Input voltage: 220V ~ 50/60Hz

Rated power: 1000W

Product net weight: 810g

Product size: 150\*145\*180mm

Product Material: ABS/Silicone

Standby power: <1W

Country of origin: China



EU Authorised Representative,  
Bonita toys sl,  
c/Zaragoza 1,3 derecha, Alicante  
03002, Spain



Waste electronic equipment and/or batteries should not be disposed of with household waste. Separate disposal facilities exist. For your nearest facilities, see [www.recycle-more.co.uk](http://www.recycle-more.co.uk) or in store for details.



## Tandem Group Trading

35 Tameside Drive  
Castle Bromwich  
Birmingham  
B35 7AG

[www.jackstonehouse.com](http://www.jackstonehouse.com)

Tel: 01604 537900

Email: [sales@jackstonehouse.com](mailto:sales@jackstonehouse.com)