

Recommended number of people for pitching: 1-2

## parts list

- 1 x Flysheet
- 1 x Bedroom
- 3 x Poles
- 1 x Peg Set

## pitching instructions

Select your site; ideally smooth ground on a slight incline (water settles on flat). Remove any debris.

(Layout the flysheet on the ground with the door facing away from the prevailing wind. If it is windy, hammer in a few pegs to stop tent blowing away. Ensure the door is zipped closed.

### A/B

Assemble the poles and push them through sleeves on the outside of the flysheet.

### C






With the poles in the sleeves and starting at one end carefully bend the first pole into an arch and insert the Pins into the ends of the poles, CAUTION should be taken whilst doing this procedure due to tension in the poles. Repeat with each pole.

### D

Insert tent pegs into the loop sections pulling the tent outwards and into shape, use of a mallet is recommended.

### E

Insert tent pegs to the base of the poles/




### F

Clip the Groundsheet and Bedroom together on the edges of the base

### G

Attach all the toggle and rings to fully tension the bedroom, start from the back of the tent. Take note to connect corresponding colour coded parts.




### H


Peg out all guyropes and peg points. Adjust guyropes to ensure even tension across all.

## guyrope tension adjuster

Each guyrope has a plastic slider, in order for this to function correctly, create a loop as shown below. Peg through this loop and move the slider up the rope to gain tension.



For optimum hold, pegs should be hammered into the ground at approx 45 degree angle. Guyropes should be 90 degrees to the peg.



## dismantling instructions

Remove all pegs and neatly roll up and tie all guyropes.

TAKE CARE-poles will be under tension when removing from pins.

Remove the poles; push out of the sleeves, do not pull.

Place poles into pole bag, pegs into peg bag. Fold the tent fabric neatly and roll around the pole bag.

Roll as tightly as possible to ensure it will fit into the tent bag.