

RECYCLING BIN

07/240 - User Guide

07/630

07/631

www.VonHaus.com

WARNINGS & PRECAUTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

This Recycling Bin is for domestic use only. Do not use for commercial purposes.

Do not use the Recycling Bin for any purpose that is not explicitly specified in this User Guide.

This product is not a toy. Children should be supervised at all times to ensure they do not play with the Recycling Bin.

WARNING! Every effort has been taken to smooth any rough edges, however, take care when handling the Recycling Bin as some edges may be sharp.

CAUTION: Keep hands and fingers away from the lid and mechanism.

Always rinse items thoroughly before recycling.

Always empty the Recycling Bin before attempting to move the unit.

CLEANING & MAINTENANCE

Keep the Recycling Bin clean so that it does not emit any unpleasant odour. Daily emptying is ideal. Wipe down with cleaning wipes or rinse well with water and mild detergent. Dry thoroughly before use.

Sprinkle some bicarbonate of soda in the bottom of each compartment to absorb any moisture and deodorize the Recycling Bin.

Compartments must be cleaned immediately if any waste has spilt.

To deep clean your Recycling Bin, rinse thoroughly, then add a gallon of warm water into a bucket along with a few drops of dish washing liquid and ½ cup of bleach. Mix the solution, then use to clean the inside and outside of the Recycling Bin with the help of a long-handled mop or brush. Rinse and dry thoroughly before placing back into position.

DISPOSAL INFORMATION

Please recycle where facilities exist. Check with your local authority for recycling advice.

WARRANTY

To register your product and find out if you qualify for a free extended warranty, go to:

www.VonHaus.com/warranty

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in the Warnings and Precautions page of this User Guide, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty.

Returned goods will not be accepted unless re-packaged in its original colour box and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring the product second-hand or for commercial or communal use.

COPYRIGHT

All material in this instruction manual are copyrighted by DOMU Brands Ltd.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.

Thank you for purchasing the Recycling Bin.

VonHaus® is a registered trademark of DOMU Brands Ltd
Made in China for DOMU Brands Ltd M24 2RW
