

BlueWhaleSpa

Changing your range between LOW/HIGH

- Press **WARM/TEMP**
- Press **LIGHT** (you will see TEMP with the RANGE flashing)
- Press **WARM/TEMP** (this should change the arrow between up and down – We recommend a HIGH range – The arrow pointing up to allow you to heat to the maximum temperature)
- Press **LIGHT**

If the RANGE is LOW – the tub will only heat to 37°C

Changing the mode

- Press **WARM/TEMP**
- Press **LIGHT**
- Press **LIGHT**
- Press **WARM/TEMP** (this will change between REST and READY – We recommend, for regular use to keep it in a READY mode)
- Press **LIGHT**

Please be aware, if in REST mode, you will see RUN PMPS FOR TEMP appear on your control panel

Checking/Changing your Time

- Press **WARM/TEMP**
- Press **LIGHT**
- Press **LIGHT** repeatedly (until SET – TIME appears)
- Press **WARM/TEMP**
- Press **WARM/TEMP** (until the correct hour is displayed)
- Press **LIGHT**
- Press **WARM/TEMP** (until the correct minute is displayed)
- Press **LIGHT**

Checking/Adjusting your Filtration Cycle

- Press **WARM/TEMP**
- Press **LIGHT**
- Press **LIGHT** repeatedly (approx 6 times) until FLTR1 appears
- Press **WARM/TEMP** (you should see BEGN on your LCD)
- Press **WARM/TEMP** (you should see the time and the HOURS flashing)
 - If you want to change the HOUR press **WARM/TEMP** until the hour you desire appears and then press **LIGHT** to save – This will change it to the minutes
 - If you want to change the the MINUTES press **WARM/TEMP** – This will adjust the minutes in 15min increments, then press **LIGHT** to save (you should then see RUN on your LCD)
- Press **WARM/TEMP** (we advise to set your filtration cycle for 2hrs – If it is not set for 2hrs, please follow the below)
 - Press **WARM/TEMP** until 2hrs is displayed on the HOURS and then press **LIGHT** to save – This will change it to the minutes
 - If you want/need to change the MINUTES then press **WARM/TEMP** – This will adjust the minutes in 15min increments, then press **LIGHT** to save (you should then see ENDS on your LCD – This will just show the end time – You can check this is right, however it isn't really necessary)
- Press **LIGHT**
- Press **LIGHT** (you should see FLTR2 appear on your LCD – If it does not, press **LIGHT** once more. You may then see OFF. If you see OFF, please press **WARM/TEMP** until you see ON)
- Press **LIGHT**
 - You will then see BEGN and can now repeat the steps as above

Locking/Unlocking your Control Panel

To **LOCK TEMP** (the temperature and any temperature settings, including but not limited to the RANGE, MODE will be locked)

- Press **WARM/TEMP**
- Press **LIGHT**
- Press **LIGHT** (until LOCK appears)
- Press **WARM/TEMP**
- Press **WARM/TEMP** (you will see OFF)
- Press **WARM/TEMP** (until you see ON)
- Press **LIGHT**

To **LOCK PANL** (no functions can be used although the automatic settings are still in place, including but not limited to the Filtration Cycle and Heating facility)

- Press **WARM/TEMP**
- Press **LIGHT**
- Press **LIGHT** (until LOCK appears)
- Press **WARM/TEMP**
- Press **LIGHT** (you will see PANL)
- Press **WARM/TEMP** (you will see OFF)
- Press **WARM/TEMP** (until you see ON)
- Press **LIGHT**

To **UNLOCK**

- Press and hold **WARM/TEMP**
- Press **LIGHT** slowly twice

To Flip your display

- Press **WARM/TEMP**
- Press **LIGHT**
- Press **LIGHT** (until FLIP appears)
- Press **WARM/TEMP** (until display is as you desire)
- Press **LIGHT**

Changing your Preferences/Turning OFF Reminders (ie: CLN FLTR)

- **Switching between °C/°F**
 - Press **WARM/TEMP**
 - Press **LIGHT** (approx. 8 times until PEF appears)
 - Press **WARM/TEMP**
 - Press **WARM/TEMP** (choose °C or °F when displayed)
 - Press **LIGHT**
- **Turning off Reminders**
 - Press **WARM/TEMP**
 - Press **LIGHT** (approx. 8 times until PEF appears)
 - Press **WARM/TEMP**
 - Press **LIGHT** (until RE – MIN – DERS appears)
 - Press **WARM/TEMP**
 - If it says ON, press **WARM/TEMP** until OFF is displayed
 - Press **LIGHT**