

Hedge Trimmer Quickstart Guide

TTHED18-3

Charging the Battery



Connect the mains charger to the charger base, now plug into a power point. A green light will illuminate on the charger base.

Charging the Battery




Slide the charger base onto the battery to start the charging of the battery. The green light will go out and be replaced with a red light to indicate charging.

Charging the Battery



When the battery is fully charged the red light will go out and the green light will illuminate to indicate charging is complete.

Starting the Hedge Trimmer



The trimmer is equipped with two switch levers, both need to be pressed for the trimmer to operate. Press and hold the safety handle switch and then pull the trigger switch to start.

Hedge Trimmer Quickstart Guide

Overview & Specifications



Box Contents

**1 x Battery &
1 x Charger
included**



**Integrated hand
safety guard
& 2 step safety
system**

Frequently Asked Questions (FAQs)

Does this hedge trimmer come with a battery and charger?

- Yes, battery and charger are included.

How long does the battery last before it needs recharging?

- Each battery lasts approx. 30mins during use.

Are spare batteries available?

- Yes, they are, search for Terratek Garden Battery.

How heavy is the hedge trimmer?

- It weighs approx. 3.5kg.

What is the charge time?

- 3 - 5 hours.

Does the hedge trimmer come with a warranty?

- Yes, a 2 year guarantee is included.

What is the total length of the hedge trimmer?

- From battery to the tip of the blade it is adjustable between 190cm – 240cm.