



Home Garden

DIRECT



www.homegardendirect.co.uk :

IR072 ROUND DINING TABLE

PRS-RND-DT-WNT-D100-01

Instruction manual


















SAFETY AND CARE ADVICE

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE

- Check you have all the components and tools listed on pages 2 or 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.




COMPONENTS — PANELS

A		1	F	 M10*70mm	1
B		1	G	 M8*30mm	6
C		1	H	 M8*16mm	8
D		1	I	 M8*18mm	14
E		1	J	 M10*18mm	1
			K	 M10	1
			L	 5#	1
			M	 6#	1


ASSEMBLY INSTRUCTIONS

step1

Dismantle part B plate first.




step2




ASSEMBLY INSTRUCTIONS

step3



step4



ASSEMBLY INSTRUCTIONS



*Congratulations!
Now you have finished assembling the product.*