

Thank you for purchasing one of our beanbags. In your box there is a vacuum-packed inner bag and a carefully folded outer bag (which has one of our delightful Disney or Marvel prints on). We suggest you get started straight away:

1. Unpack the vacuumed inner bag. It will no doubt seem a little flat – well wouldn't you if you'd been stuffed inside a box – and like any of us the inner will come back to life if you give it a little love.
2. The foam pieces which make up the interior of the bean bag (and a very comfy seat for your little one), have been treated to UK safety standards, meaning they have a tendency to stick to each other, so we suggest you *crumble* and break up the clumps of foam.
3. Give it a good crumble and massage and leave it for 24 hours, then repeat again, at this point the foam pieces will have all expanded and taken their original form, please be patient it can take up to 48 hours for your bean bag to be back on full form.
4. Put the outer cover on, secure using the zip and let your little one kick back and relax in their new seat.

Disney HOME