


# Mickey Bent Wood U Stool

520877



## **IMPORTANT!**

### **Care and Maintenance of your Furniture**

THIS PRODUCT IS FINISHED WITH CLEAR LACQUER.

Use a soft cloth that has been dampened in water to clean the surface of this product. Do not use abrasive cleaners, furniture wax or polish on the surface of this product, as it may damage the surface.

**CAUTION: FREQUENT EXPOSURE TO DIRECT SUNLIGHT OR SIMILAR SOURCES MAY CAUSE THE SURFACE TO DISCOLOUR OR FADE.**

## **WARNING!**

Do NOT place this product near a window as it can be used as a step by the child and cause the child to fall out of the window.

Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product.

DO NOT place this product near a window where cords from blinds or curtains may strangle a child.

2022-10-31

Sourcebynet UK Limited  
Unit 8, Nine Bridges, Vanguard Way,  
Battlefield Enterprise Park, Shrewsbury,  
SY1 3TG, UK