USER GUIDE

5-TIERS SHOES RACK

SAFETY & WARNINGS

Warning

- The product contains small parts and sharp objects, please be careful during assembly and keep children away.
- Keep plastic bags away from children in case of suffocation.
- Please make sure to keep the item away from extreme conditions (such as high humidity, high temperatures, intense sunlight, excess water, etc.)
- Do not place any sharp objects or corrosive materials on the product to avoid any damage. In cases of placing sharp footwear like ice skates, please use blade guards.
- Please do not force large size shoes into the product in order to avoid deformation.
- Please do not place overweight objects, do not stand on the product and keep children away from jumping on the product.

Important

- Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
- Do not over tighten screws and bolts to avoid stripping.
- Please use hand tools to assemble this product. Do not use power tools.
- Do not sit on the shoe rack. Do not drop heavy items on the shoe rack.
- Do not move the shoe rack while loaded.
- Do not move the shoe rack by lifting the poles, use the handles at the top of each side frame.

COMPONENTS



A x 12PCS

B x 8PCS

C x 8PCS

D x 4PCS



E x 6PCS

F x 2PCS

INSTALLATION

Step 1

Connect the right ends of four A to E.



Step 2

Connect the left ends of four A to E.

Step 3

Insert four B into each hole in the four corners of E.



Step 4

Repeat the above steps to get the four-tier shoe rack.

Step 5

Complete the stand of the shoe rack by inserting four C into each hole underneath the four corners of E. Connect four D to the bottom of the four C.



Step 6

Install the top shelf stopper by using four C and two F.

CLEANING & CARE

- Clean the product with a dry soft cloth. Avoid cleaning the product with a hard item or chemically unsuitable product.
- Please make sure to keep your items and shoes clean before placing them.
- In case of using a mildly wet cloth, please make sure to dry the surfaces immediately after cleaning.
- When disassembling the item, please make sure to use the same tools required for assembly.
- If something is stuck on the surfaces, do not use abrasive tools to remove them, as these could leave scratches or marks. Please use lint-free cloths or sponges instead.
- This product should not be discarded with household waste. Take to your local authority waste dispoal centre.

Living and Home
A Home is for Living in

For comfort and style update your living space.
Browse contemporary and classic designs and find the perfect home to your look and the perfect spot to lounge.
Put your feet up and sink into our stylish home decor.
We are mainly engaged in home, outdoor, home appliances, office, bathroom, provided high quality and affordable products for you. We value every one of our customers and our professional service team is always available to help you.

livingandhome.co.uk