

# PRO-ELEC

## 13A 250V EXTENSION LEAD SWITCHED OR UNSWITCHED




### IMPORTANT PRODUCT SAFETY INFORMATION



- ✓ DO check the user manual provided with all high powered domestic appliances including kitchen appliances and air conditioning units for suitability before connecting to an extension lead.
- ✓ DO ensure the mains cable must be fully unwound before use.
- ✓ DO position an extension lead carefully to prevent any risk of damage or a trip hazard. If the cable has to cross a pathway, cover it with a rubber protector strip.
- ✓ DO check that the extension cable is suitable for your local mains voltage and socket.
- ✓ DO check that plugs and sockets are undamaged before use and the cable is not damaged due to being walked over, continually bent at the same point, or stored badly.
  
- ✗ DO NOT remove the fused plug and connect directly to a mains supply.
- ✗ DO NOT use extension cables with multi-way adapters or adapter blocks, as this can overload the socket which increases the risk of fire.
- ✗ DO NOT connect multiple extension leads together.
- ✗ DO NOT exceed the total maximum load across all outlets of 13A / 3120W.
- ✗ DO NOT push objects other than the appliance plug into the extension cable sockets.
- ✗ DO NOT use in damp conditions.
- ✗ DO NOT use outdoors - for indoor use only.

### RECOMMENDED USAGE


- ✓ Disconnect the power before connecting equipment to the extension lead sockets.
- ✓ An extension lead should only be used when it is not possible to reach a wall socket with the appliance cable.
- ✓ BEWARE power tools used with extension cables can frequently become tangled.
- ✓ BEWARE high power equipment such as kitchen appliances may overload the extension lead, always check the safety instructions supplied with the appliance before use.



**Safety Shutters**



**Fire Retardent Materials**



**13A Plug Fuse**