



# ATARI FLASHBACK® 12

## Instruction Manual

MODEL NO.: AR3070B

### IMPORTANT: READ BEFORE USE


In very rare circumstances, some people may experience epileptic seizures when viewing flashing lights or patterns in our everyday life. Flashing lights and patterns are also common to almost any video game. Please consult your physician before playing ANY video game if you have had an epileptic condition or seizure OR if you experience any of the following while playing - Altered vision, eye or muscle twitching, mental confusion or disorientation, loss of awareness of the surroundings or involuntary movements. It is advised to take a 20-minute rest after 1 hour of continuous play.

## Atari Flashback® 12 Console

Appearance and Key List

The image below shows the location of the connectors and buttons. Each function is outlined below the image.

- 1 Power
- 2 Difficulty Switch - Left Player
- 3 Difficulty Switch - Right Player
- 4 Game Select
- 5 Game Reset
- 6 Left Player Game Controller Jack
- 7 Right Player Game Controller Jack
- 8 HDMI Output
- 9 Micro USB Adaptor Jack
- 10 System Reset



### NOTE

- Must use the Micro USB adaptor included as the power supply to the console.
- Do not connect the Micro USB adaptor to a power input other than the below specifications.
- Micro USB adaptor is not a toy.
- The socket-outlet should be installed near the equipment and should be easily accessible.

### What do I do when the power supply is not working?

You might be using the wrong Micro USB adaptor. Please use the one included in the package, which is rated for 5V/1A.

### Micro USB Adaptor Specification


INPUT:  
100V-240V AC/50HZ-60HZ  
OUTPUT: 5V/1A

## Wired Game Controller

Appearance and Key List

The image below shows the location of the connectors and buttons. Each function is outlined below the image.

- 1 Joystick
  - 2 Fire Button
- ### P1 ONLY
- 3 MENU
  - 4 SELECT
  - 5 START
  - 6 REWIND



## How Do I Use Wired Controllers?

### What are the two controller ports on the console for?

These ports are for the included wired joysticks.

These ports are also compatible with original Atari 2600 wired joysticks and paddle controllers.

### How do I connect wired controllers?

For 1 player games:  
Connect a wired controller to the left controller port.

For 2 player games:  
Connect a second wired controller to the right controller port for player two.

### What do I do when the controller is not working?

If you only have a controller plugged into the P2 socket, turn off your console and connect the controller to the P1 (left) controller port. Then, turn on the console and try again.

You may notice a slight delay when controlling games with a joystick controller that were originally designed for paddle controllers. For these paddle games, please use paddle controllers (not included) for the best gameplay experiences.

## How Do I Connect The Console To The TV?

Connect the game console to TV using an HDMI cable.

NOTE: HDMI cable is not included.




Flip the switch on the game console after configuring the TV input to the selected HDMI source.

### NOTE

Display results will vary by TV. Consult your TV's manual to adjust Brightness, Sharpness, Contrast, Aspect Ratio, and other features for best display results.

## How do I start playing?



Flip the switch to turn on the game console.

Use the controller that is connected to the port to browse menu and select game. Move the joystick left and right to navigate the menu pages, and move up and down to highlight games on each page.



Press FIRE on the controller to select the highlighted game.




Press the button to begin the game. Note that for some games, pressing the controller button begins the game.

### How do I play the 3- and 4-player games?

The 3- and 4-player games are designed for paddle controllers. Please plug your paddle controllers into each controller port on the game console.

NOTE: Paddles are not included.



### How do I rewind the game?

Press REWIND on player 1 (P1) controller to rewind gameplay as far back as needed.

### How do I save/load game state?

Press DOWN and SELECT or Press MENU on controller to display in-game menu. Move the joystick controller to SAVE SLOTS. Press FIRE to enter SAVE/LOAD the gameplay.

## How do I adjust the game level?



Press the button on the game console.



Press the button to begin the adjusted level.

## How do I go back to game menu while playing the game?



Press DOWN and SELECT or Press MENU on controller to display in-game menu, select Quit to go back to the game menu page.

### Safety Notice

Do not submerge the game console in water or expose it to extreme heat or to strong magnetic fields. Doing so may cause permanent damage to your game player. Always use a dry towel to clean the game console and controllers. Transformers are suitable for indoor use only. Transformers and power supplies for toys are not intended to be used as toys, and the use of this product by children under 15 years old should be under parental supervision.

# GAME LIST (110)

3-D Tic-Tac-Toe	Frog Pond	Return to Haunted House
Adventure®	Front Line™	River Raid™
Adventure® II	Frostbite™	Saboteur®
Air-Sea Battle	Fun with Numbers	Save Mary
Aquaventure®	Golf	Sequest™
Asteroids®	Gravitar®	Secret Quest
Asteroids® Deluxe	H.E.R.O.™	Sky Diver
Atari Climber	Hangman	Slot Machine
Backgammon	Haunted House®	Slot Racers
Basketball	Home Run	Solaris™
Beamrider™	Human Cannonball	Space Invaders™
Black Jack	Indy 500	Space Raid
Bowling	Jungle Hunt™	Space War
Breakout®	Kaboom!™	Sprintmaster
BurgerTime™	Keystone Kapers™	Stampede™
Burnin' Rubber™	Lock 'n' Chase™	Star Ship
Canyon Bomber®	Maze Craze	Starmaster™
Centipede®	Megamania™	Steeplechase
Championship Soccer	Millipede®	Stellar Track
Chopper Command™	Miniature Golf	Street Racer
Circus Atari®	Missile Command®	Submarine Commander®
Combat®	MotoRodeo	Super Baseball
Combat® Two	Night Driver	Super Breakout
Cosmic Commuter™	Off The Wall	Super Football
Crackpots™	Oink!™	Surround
Crystal Castles®	Outlaw	Swordquest® Earthworld
Decathlon	Pitfall!™	Swordquest® Fireworld
Demons to Diamonds	Polaris™	Swordquest® Waterworld
Desert Falcon	Pong® (Video Olympics)	Tempest®
Dodge 'Em	Pressure Cooker™	Video Checkers
Double Dunk	Radar Lock	Video Chess
Dragster	Realsports® Baseball	Video Pinball
Enduro™	Realsports® Basketball	Warlords®
Fatal Run®	Realsports® Boxing	Wizard
Fishing Derby™	Realsports® Football	Yars' Return
Flag Capture	Realsports® Soccer	Yars' Revenge®
Football	Realsports® Volleyball	



## How do I update firmware?

1. Please go to the Firmware Update Portal (<https://firmwareupdate.atgames.net/>) to download necessary document and tool.
2. Unzip DriverAssistant\_v4.8.zip and run DriverInstall.exe to install the driver on a Windows PC.
3. Connect your console to the PC with micro USB cord. Unzip AndroidTool\_Release\_v2.69.zip and run AndroidTool.exe.
4. Use a pin to press and hold the recovery button until the tool shows "Found One LOADER Device" on the PC. Click the tab "Upgrade Firmware" and the button "Firmware".
5. Locate the firmware image on the PC then proceed to upgrade. A prompt "Reset Device Success" will show.
6. Turn off the console and disconnect it from the PC.
7. Create a "Game" directory on the root of the USB drive. The console only takes game files with ".a26" extensions. Other file extensions will not work. Copy these files to the "Game" directory.
8. Connect the power cable and the USB drive to the console using the Y cable and turn the console on to finish the update process.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SPACE INVADERS™© TAITO CORPORATION 1978 ALL RIGHTS RESERVED.  
 JUNGLE HUNT™© TAITO CORPORATION 1982 ALL RIGHTS RESERVED.  
 FRONT LINE™© TAITO CORPORATION 1982 ALL RIGHTS RESERVED.  
 POLARIS™© TAITO CORPORATION 1980 ALL RIGHTS RESERVED.  
 The versions of SPACE INVADERS™, JUNGLE HUNT™, FRONT LINE™, and POLARIS™ included in the Atari Flashback® are based on those created for the ATARI 2600® and therefore may differ in appearance and performance from the original arcade and console editions developed by TAITO Corporation.

Space Raid for Atari VCS/2600.  
 Game © Copyright 2013 Oscar Toledo Gutierrez.  
 Box design courtesy of CollectorVision Games, Inc.

Asteroids Deluxe Program & Audiovisual © 2005 Atari, Inc.



The Adopted Trademarks HDMI, HDMI High Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



© 2023 Atari Interactive, Inc.  
 ATARI and the ATARI logo are trademarks of Atari Interactive, Inc. in the U.S. and other countries. All individual Atari game names and logos are trademarks or registered trademarks of Atari Interactive, Inc. or its affiliates in the U.S. and other countries. All other trademarks are the properties of their respective owners. All Rights Reserved.

© 2023 Activision Publishing, Inc. ACTIVISION is a registered trademark, and H.E.R.O. and PRESSURE COOKER are trademarks of Activision Publishing, Inc.



SCAN

AND FIND OUT MORE ABOUT THIS PRODUCT!

More Classics at [www.atgames.us](http://www.atgames.us)

THE SOURCE  
[www.thesourcewholesale.co.uk](http://www.thesourcewholesale.co.uk)

Imported by The Source Wholesale RH4 1XA UK  
 The Source Wholesale B.V. 1114 AB Amsterdam-Duivendrecht

Please retain the important information on this packaging for future reference.

**ATGAMES**  
 © 2023 AtGames Interactive

[www.atgames.net](http://www.atgames.net)  
 PO Box 1691, El Segundo, CA 90245  
 All rights reserved.  
 Made in China

Size: W297xH210mm\_(A4) Double-sided monochrome printing  
Print bleed: 3mm

AtGames AI Games Interactive [www.atgames.net](http://www.atgames.net)



# ATARI FLASHBACK® 12

## Instruction Manual

MODEL NO.: AR3070B

### IMPORTANT: READ BEFORE USE


In very rare circumstances, some people may experience epileptic seizures when viewing flashing lights or patterns in our everyday life. Flashing lights and patterns are also common to almost any video game. Please consult your physician before playing ANY video game if you have had an epileptic condition or seizure OR if you experience any of the following while playing - Altered vision, eye or muscle twitching, mental confusion or disorientation, loss of awareness of the surroundings or involuntary movements. It is advised to take a 20-minute rest after 1 hour of continuous play.

### Atari Flashback® 12 Console

#### Appearance and Key List

The image below shows the location of the connectors and buttons. Each function is outlined below the image.

- 1 Power
- 2 Difficulty Switch - Left Player
- 3 Difficulty Switch - Right Player
- 4 Game Select
- 5 Game Reset
- 6 Left Player Game Controller Jack
- 7 Right Player Game Controller Jack
- 8 HDMI Output
- 9 Micro USB Adaptor Jack
- 10 System Reset



#### NOTE

- Must use the Micro USB adaptor included as the power supply to the console.
- Do not connect the Micro USB adaptor to a power input other than the below specifications.
- Micro USB adaptor is not a toy.
- The socket-outlet should be installed near the equipment and should be easily accessible.

#### What do I do when the power supply is not working?

You might be using the wrong Micro USB adaptor. Please use the one included in the package, which is rated for 5V/1A.

#### Micro USB Adaptor Specification

INPUT:  
100V-240V AC/50HZ-60HZ  
OUTPUT: 5V/1A

### Wired Game Controller


#### Appearance and Key List

The image below shows the location of the connectors and buttons. Each function is outlined below the image.

- 1 Joystick
- 2 Fire Button

#### P1 ONLY

- 3 MENU
- 4 SELECT
- 5 START
- 6 REWIND



### How Do I Use Wired Controllers?

#### What are the two controller ports on the console for?

These ports are for the included wired joysticks.

These ports are also compatible with original Atari 2600 wired joysticks and paddle controllers.

#### How do I connect wired controllers?

For 1 player games:  
Connect a wired controller to the left controller port.

For 2 player games:  
Connect a second wired controller to the right controller port for player two.

#### What do I do when the controller is not working?

If you only have a controller plugged into the P2 socket, turn off your console and connect the controller to the P1 (left) controller port. Then, turn on the console and try again.

You may notice a slight delay when controlling games with a joystick controller that were originally designed for paddle controllers. For these paddle games, please use paddle controllers (not included) for the best gameplay experiences.

### How Do I Connect The Console To The TV?

Connect the game console to TV using an HDMI cable.

NOTE: HDMI cable is not included.



Flip the switch on the game console after configuring the TV input to the selected HDMI source.

#### NOTE

Display results will vary by TV. Consult your TV's manual to adjust Brightness, Sharpness, Contrast, Aspect Ratio, and other features for best display results.

### How do I start playing?

Flip the switch to turn on the game console.

Use the controller that is connected to the port to browse menu and select game. Move the joystick left and right to navigate the menu pages, and move up and down to highlight games on each page.




Press FIRE on the controller to select the highlighted game.



Press the button to begin the game. Note that for some games, pressing the controller button begins the game.

### How do I play the 3- and 4-player games?

The 3- and 4-player games are designed for paddle controllers. Please plug your paddle controllers into each controller port on the game console.



NOTE: Paddles are not included.

### How do I rewind the game?

Press REWIND on player 1 (P1) controller to rewind gameplay as far back as needed.

### How do I save/load game state?

Press DOWN and SELECT or Press MENU on controller to display in-game menu. Move the joystick controller to SAVE SLOTS. Press FIRE to enter SAVE/LOAD the gameplay.

### How do I adjust the game level?

Press the button on the game console.

Press the button to begin the adjusted level.

### How do I go back to game menu while playing the game?

Press DOWN and SELECT or Press MENU on controller to display in game menu, select Quit to go back to the game menu page.

#### Safety Notice

Do not submerge the game console in water or expose it to extreme heat or to strong magnetic fields. Doing so may cause permanent damage to your game player. Always use a dry towel to clean the game console and controllers. Transformers are suitable for indoor use only. Transformers and power supplies for toys are not intended to be used as toys, and the use of this product by children under 15 years old should be under parental supervision.

## GAME LIST (110)

3-D Tic-Tac-Toe	Frog Pond	Return to Haunted House
Adventure®	Front Line™	River Raid™
Adventure® II	Frostbite™	Saboteur®
Air-Sea Battle	Fun with Numbers	Save Mary
Aquaventure®	Golf	Seaquest™
Asteroids®	Gravitar®	Secret Quest
Asteroids® Deluxe	H.E.R.O.™	Sky Diver
Atari Climber	Hangman	Slot Machine
Backgammon	Haunted House®	Slot Racers
Basketball	Home Run	Solaris™
Beamrider™	Human Cannonball	Space Invaders™
Black Jack	Indy 500	Space Raid
Bowling	Jungle Hunt™	Space War
Breakout®	Kaboom!™	Sprintmaster
BurgerTime™	Keystone Kapers™	Stampede™
Burnin' Rubber™	Lock 'n' Chase™	Star Ship
Canyon Bomber®	Maze Craze	Starmaster™
Centipede®	Megamania™	Steeplechase
Championship Soccer	Millipede®	Stellar Track
Chopper Command™	Miniature Golf	Street Racer
Circus Atari®	Missile Commander®	Submarine Commander®
Combat®	MotoRodeo	Super Baseball
Combat® Two	Night Driver	Super Breakout
Cosmic Commuter™	Off The Wall	Super Football
Crackpots™	Oink!™	Surround
Crystal Castles®	Outlaw	Swordquest® Earthworld
Decathlon	Pitfall™	Swordquest® Fireworld
Demons to Diamonds	Polaris™	Swordquest® Waterworld
Desert Falcon	Pong® (Video Olympics)	Tempest®
Dodge 'Em	Pressure Cooker™	Video Checkers
Double Dunk	Radar Lock	Video Chess
Dragster	Realsports® Baseball	Video Pinball
Enduro™	Realsports® Basketball	Warlords®
Fatal Run®	Realsports® Boxing	Wizard
Fishing Derby™	Realsports® Football	Yars' Return
Flag Capture	Realsports® Soccer	Yars' Revenge®
Football	Realsports® Volleyball	



#### How do I update firmware?

1. Please go to the Firmware Update Portal (<https://firmwareupdate.atgames.net/>) to download necessary document and tool.
2. Unzip DriverAssistant\_v4.8.zip and run DriverInstall.exe to install the driver on a Windows PC.
3. Connect your console to the PC with micro USB cord. Unzip AndroidTool\_Release\_v2.69.zip and run AndroidTool.exe.
4. Use a pin to press and hold the recovery button until the tool shows "Found One LOADER Device" on the PC. Click the tab "Upgrade Firmware" and the button "Firmware".
5. Locate the firmware image on the PC then proceed to upgrade. A prompt "Reset Device Success" will show.
6. Turn off the console and disconnect it from the PC.
7. Create a "Game" directory on the root of the USB drive. The console only takes game files with ".a26" extensions. Other file extensions will not work. Copy these files to the "Game" directory.
8. Connect the power cable and the USB drive to the console using the Y cable and turn the console on to finish the update process.

#### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

SPACE INVADERS™ © TAITO CORPORATION 1978 ALL RIGHTS RESERVED.  
JUNGLE HUNT™ © TAITO CORPORATION 1982 ALL RIGHTS RESERVED.  
FRONT LINE™ © TAITO CORPORATION 1982 ALL RIGHTS RESERVED.  
POLARIS™ © TAITO CORPORATION 1980 ALL RIGHTS RESERVED.  
The versions of SPACE INVADERS™, JUNGLE HUNT™, FRONT LINE™, and POLARIS™ included in the Atari Flashback® are based on those created for the Atari 2600® and therefore may differ in appearance and performance from the original arcade and console editions developed by TAITO Corporation.

Space Raid for Atari VCS/2600.  
Game © Copyright 2013 Oscar Toledo Gutierrez.  
Box design courtesy of CollectorVision Games, Inc.

Asteroids Deluxe Program & Audiovisual © 2005 Atari, Inc.

The content of this document is subject to change without notice.



SCAN AND FIND OUT MORE ABOUT THIS PRODUCT! More Classics at [www.atgames.us](http://www.atgames.us)

THE SOURCE  
[www.thesourcewholesale.co.uk](http://www.thesourcewholesale.co.uk)  
Imported by The Source Wholesale RH4 1XA UK  
The Source Wholesale B.V. 1114  
AB Amsterdam-Duivendrecht  
Please retain the important information on this packaging for future reference.

AtGames  
© 2023 AtGames Interactive

[www.atgames.net](http://www.atgames.net)  
PO Box 1691, El Segundo, CA 90245  
All rights reserved.  
Made in China



The Adopted Trademarks HDMI, HDMI High Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



© 2023 Atari Interactive, Inc. ATARI and the ATARI logo are trademarks of Atari Interactive, Inc. in the U.S. and other countries. All individual Atari game names and logos are trademarks or registered trademarks of Atari Interactive, Inc. or its affiliates in the U.S. and other countries. All other trademarks are the properties of their respective owners. All Rights Reserved.

© 2023 Activision Publishing, Inc. ACTIVISION is a registered trademark, and H.E.R.O. and PRESSURE COOKER are trademarks of Activision Publishing, Inc.