


USER'S MANUAL



METAL STORAGE SHED

PM1357, PM1358

Please read this manual carefully before assembly and keep it properly.

BEFORE YOU START

Assembly Instructions

Before starting the assembly, verify local building codes for footing, location, and other requirements. Review all instructions before starting, and carefully follow the step sequence during the assembly.

Parts and Parts List

Ensure you have all the necessary parts. Organize the contents of the carton by part number referring to the parts list. The first few steps demonstrate how to assemble related parts into larger sub-assemblies for later use. Familiarize yourself with the included hardware and fasteners to streamline the assembly process. Please note that extra fasteners are included for your convenience.

Check the Weather

Ensure the weather the day chosen for installing the shed is fine. Avoid assembling on windy days, and exercise caution on wet or muddy ground.


Teamwork

Whenever possible, engage two or more individuals on the assembly. One person can position parts or panels while the other handles fasteners and tools.

Tools and Materials

Here are some essential tools and materials for the assembly. Determine the anchoring method and foundation type you intend to use to make a comprehensive list of required materials.

Required Tools



CARE & MAINTENANCE

Finish

For a long-lasting finish, regularly clean and wax the exterior surface. Address scratches promptly by cleaning the area with a wire brush, washing it, and applying touch-up paint according to the manufacturer's recommendation.

Roof

Keep the roof clear of leaves and snow with a long-handled, soft-bristled broom. Excessive snow on the roof can damage the shed. In snowy areas, Roof Strengthening Kits are available for most Arrow Buildings, providing added protection against heavy snow accumulation.

Doors

Ensure the door tracks are free of dirt and debris. Lubricate the door track annually with furniture polish or silicone spray. Keep doors closed and locked to prevent wind damage.

Fasteners

Use all supplied washers for protection against weather infiltration and prevention of screw scratches to the metal. Regularly inspect the shed for loose screws, bolts, nuts, etc. and re-tighten them as necessary.

Moisture

Reduce condensation by placing a plastic sheet (vapor barrier) under the entire floor area.

Other Tips...

Wash off inked part numbers on coated panels with soap and water.


Use silicone caulking for watertight seals throughout the shed.

Avoid storing swimming pool chemicals in the shed.

Store combustibles and corrosives in airtight approved containers.

WARNING

1. Carefully read the instructions and strictly follow them during assembly and use.
2. Double-check to ensure that all parts in the package are intact.
3. Use an electric screwdriver for secure assembly.
4. Be careful when handling the metal parts of the shed as they may have sharp edges. Wear appropriate protective equipment such as gloves during assembly to avoid accidental cuts or abrasions.
5. Some parts of the shed can be heavy. If necessary, use aids to prevent injury.
6. Ensure that the shed is securely anchored to the ground or a stable surface according to the assembly instructions. Failure to do so may result in instability or overturning, causing personal injury or property damage.
7. When using the lockable door, keep the key out of reach of children and pets to prevent accidental locking or entrapment.
8. Although the shed is weatherproof, extreme weather conditions such as high winds or heavy snow may affect its stability. Please inspect the shed regularly and reinforce it as necessary to withstand severe weather conditions.
9. Inspect the shed regularly for signs of wear, damage or corrosion. Replace any worn or damaged parts immediately to maintain safety and structural integrity.
10. Reduce the risk of accidents by placing the shed in a designated area away from high-traffic areas or areas where children often play.
11. Properly dispose of packaging materials to prevent tripping or accidental ingestion by children or pets.









































This product requires two individuals for installation, taking approximately 2-3 hours.












Wear gloves to prevent injuries.


Use an electric screwdriver for secure assembly.

PARTS LIST

NO.	PART	QTY
1		2
3		1
4		1
P2		2
DF		1
DG		1
10		1
12		1
P3		6
P4		1
P4A		1
P4B		1
29R		1
29L		1
21L		1
21R		1
9		1
11L		1
11R		1




NO.	PART	QTY
JM6		4
DRA		1
DLA		1
DC		2
DH		4
JM5		4
15L		1
15R		1
G3		2
DK		3
DJ		4
15		1
8		1
18		2
16		1
P5		2
P6		1
P7		1
P8		1


NO.	PART	QTY
20U		2
20D		2
DX2		4
F1		235
F2		10
F3		32
V2		185
M8		2
B2		1
F6		4
B1		2






ASSEMBLY GUIDE




STEP 01



PART	NO.	QTY
	1	2
	4	1
	F1	4

PART	NO.	QTY
	V2	4








STEP 02

PART	NO.	QTY
	3	1
	F1	4
	V2	4







STEP 03

PART	NO.	QTY
	JM5	4
	F1	16
	V2	16







STEP 04

PART	NO.	QTY
	F6	4




STEP 05




PART	NO.	QTY
	P3	2
	F1	6
	V2	6





X2




STEP 06

PART	NO.	QTY
	P4A	1
	P4B	1
	F1	6




PART	NO.	QTY
	V2	6




X2







STEP 07

PART	NO.	QTY
	P2	2
	F1	6
	V2	6




STEP 08



PART	NO.	QTY
	12	1
	F1	6
	V2	6




X2







STEP 09


PART	NO.	QTY
	11L	1
	11R	1






STEP 10




PART	NO.	QTY
	11L	1
	11R	1
	F1	4

PART	NO.	QTY
	V2	4







STEP 11

PART	NO.	QTY
	P3	2
	F1	20
	V2	20







STEP 12

PART	NO.	QTY
	P3	2
	F1	16
	V2	16






STEP 13

PART	NO.	QTY
	P4	1
	F1	4
	V2	4




STEP 14




PART	NO.	QTY
	JM6	4
	F1	16





X4





STEP 15

PART	NO.	QTY
	29L	1
	29R	1
	F1	8

PART	NO.	QTY
	V2	8






X2



X2


STEP 16

PART	NO.	QTY
	F1	4
	V2	4




X2

A







X2


B




STEP 17

PART	NO.	QTY
	15L	1
	15R	1
	F2	6




PART	NO.	QTY
	V2	6




X2





STEP 18




PART	NO.	QTY	NOTE
	10	1	Pin holes are located on the left door and 10. When installing 10, pay attention to the location of the pin holes (a little to the left) and make sure they overlap!
	F1	6	
	V2	6	








X2






STEP 19


PART	NO.	QTY
	21L	1
	21R	1
	F1	8

PART	NO.	QTY
	F2	2
	V2	10





STEP 20

PART	NO.	QTY
	9	1
	F1	3
	F2	2



PART	NO.	QTY
	V2	3


NOTE
As described in STEP 18, 9 is not in the middle of 10, but a little to the left.







STEP 21


PART	NO.	QTY
	F1	12
	F3	16




X4








STEP 22

PART	NO.	QTY
	F1	24





STEP 23


PART	NO.	QTY
	F1	8





STEP 24

PART	NO.	QTY
	F3	16







STEP 25


PART	NO.	QTY
	F1	43
	V2	43

INSIDE




x3

OUTSIDE






STEP 26

PART	NO.	QTY
	F1	9



STEP 27

PART	NO.	QTY
	G3	2
	M8	2



STEP 28

