

## Dimensions

- Panel Size: 2400mm (L) × 600mm (W) × 21 mm (D)
- Wood Slats: 27mm (W) × 13mm (D)
- PET Backing Felt: 9mm (D)
- Approx. Weight 13kgs

## Veneer Faces

- Our panels are available in a range of wood and composites and samples can be ordered on our website.

## Preparations

- The surface you are mounting onto needs to be clean and dry. Ensure it is free from fixings such as nails and screws.

## Fixtures and Fittings

- It is possible to mount brackets and shelving over the panels. Please ensure they are securely fastened to the wall behind.

## Installation

- Screw directly through the backing felt between the slats, into the wall. We recommend using 15 black plasterboard screws (approx. 32mm × 3.5mm).
- Evenly space the screws across the panel in 5 rows.
- Please ensure the fixings are into as many of the structural joists as possible if installing panels to the ceiling.
- If you are installing the panels onto a brick wall then we recommend screwing horizontal timber battens to the wall at 600mm intervals and then screw the panels to the battens. This is much faster and easier.
- To achieve the best Class A acoustic performance the panels need to be installed on 45mm timber battens with 45mm acoustic insulations between. (EN ISO 11654: 1997).

## Cutting

- Measure twice, cut once.
- You can cut the panels with a fine tooth handsaw or most handheld saws.
- The backing felt can be cut with a sharp Stanley knife.
- For best results we recommend using a new blade on your tools.

