




## INSTALLATION INSTRUCTIONS




Step 1: Prepare all the tools and materials you need




Step 2: Measure and plan the wall




Step 3: Apply glue to the back of the wall board




Step 4: Install the columns as planned



Step 5: Cut the appropriate lengths according to the gap dimensions




Step 6: Install the remaining sections in turn




Step 7: Installation is complete


### ALTERNATIVE PATTERNS USING MITRES



Mitre cut the MDF planks at a 60° angles on both ends. These shaped wall boards can be constructed into hexagonal patterns for a more unique design



Mitre cut the MDF planks at 60° on one end and 30° on the other. These mitred wall boards can be constructed into a diamond pattern



Plan the octagonal pattern and mitre the cuts to make the boards match the plan. The mitres should be around 67° and match on both ends