


WHITE MALVERN 3 DRAWER BEDSIDE ASSEMBLY INSTRUCTIONS



FOR DOMESTIC USE ONLY

IMPORTANT

PLEASE READ BEFORE YOU CONTINUE FURTHER

THE PRODUCT YOU HAVE PURCHASED WILL GIVE YOU MANY YEARS OF SERVICE IF YOU FOLLOW THE GUIDELINES FOR ITS SAFE ASSEMBLY AND PERIODIC MAINTENANCE AND CLEANING.

ASSEMBLE ON A SOFT CLEAN SURFACE.

DO NOT USE ANY TOOLS OTHER THAN THOSE SHOWN.


ANY SPANNERS OR ALLEN KEYS REQUIRED ARE INCLUDED WITH THE FITTING KIT.

DO NOT FOR ANY REASON USE A POWER TOOL TO ASSEMBLE THIS PRODUCT. ITS USE WILL INVALIDATE ANY CLAIM YOU MAY HAVE AND COULD MAKE THIS PRODUCT UNSAFE.

DEPENDING ON THE AMOUNT OF USE THIS PRODUCT RECEIVES. IT MAY BE NECESSARY TO TIGHTEN UP THE FIXINGS FROM TIME TO TIME. THIS IS COMPLETELY NORMAL FOR ANY FLAT PACK FURNITURE. DO NOT OVERTIGHTEN FIXINGS.

FOR CLEANING, YOU MAY USE A DAMP CLOTH (NOT WET). DO NOT USE POLISH, DETERGENT OR CHEMICAL CLEANERS.










THIS SURFACE OF THIS ITEM IS NOT HEAT RESISTANT. ALWAYS USE A PLACE MAT UNDER HOT OR COLD ITEMS TO PREVENT MARKING.



PART LIST


<u>Part Number</u>	<u>Part Code</u>	<u>Part Description</u>	<u>Quantity</u>	<u>Carton</u>
01	S100-103-068-ZF1-01	Left Panel	1	1/1
02	S100-103-068-ZF1-02	Right Panel	1	1/1
03	S100-103-068-ZF1-03	Drawer Front	3	1/1
04	S100-103-068-ZF1-04	Drawer Left Panel	3	1/1
05	S100-103-068-ZF1-05	Drawer Right Panel	3	1/1
06	S100-103-068-ZF1-06	Top Support Panel	1	1/1
07	S100-103-068-ZF1-07	Centre Support Panel	2	1/1
08	S100-103-068-ZF1-08	Bottom Support Panel	2	1/1
09	S100-103-068-ZF1-09	Top Panel	1	1/1
10	S100-103-068-ZF1-10	Drawer Back Panel	3	1/1
11	S100-103-068-ZF1-11	Drawer Bottom Panel	3	1/1
12	S100-103-068-ZF1-12	Back Panel	1	1/1

HARDWARE LIST


No.	Part Name		Qty
A	Cam Nut		18
B	Cam Bolt		18
C	M8 x 25mm Wood Dowel		20
D	38mm Chipboard Screw		12
E	14mm Chipboard Screw		34
F	14" Drawer Slide		3 sets
G	PVC L Braket		1
H	Plastic Foot		4
J	18mm Panel Pin		20

TIPS FOR FITTING CAM-LOCKS

WHEN FITTING THE CAM-LOCK
 ENSURE STARTING POSITION IS CORRECT
 BEFORE YOU INSERT CONNECTING CAM BOLT
 TURN CLOCKWISE UNTIL SECURE




CORRECT **WRONG**



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example below)



Shoulder

Panel

Panel

STEP 1

PARTS REQUIRED


01 - LEFT PANEL x1

HARDWARE REQUIRED


E  09

F  03

TOOLS REQUIRED



To Assemble the Drawer Slide, Please Follow Step as Below



STEP 2

PARTS REQUIRED


02 - RIGHT PANEL x1

HARDWARE REQUIRED


E  09

F  03

TOOLS REQUIRED



To Assemble the Drawer Slide, Please Follow Step as Below






STEP 3



PARTS REQUIRED

01 - LEFT PANEL	x1
02 - RIGHT PANEL	x1

HARDWARE REQUIRED

A		04
B		08
C		04

TOOLS REQUIRED






STEP 4



PARTS REQUIRED

06 - TOP SUPPORT PANEL	x1
07 - CENTRE SUPPORT PANEL	x1
08 - BOTTOM SUPPORT PANEL	x1
09 - TOP PANEL	x1

HARDWARE REQUIRED

A		08
B		04
C		10

TOOLS REQUIRED





STEP 5

PARTS REQUIRED

- 02 - RIGHT PANEL x1
- 06 - TOP SUPPORT PANEL x1
- 07 - CENTRE SUPPORT PANEL x2
- 08 - BOTTOM SUPPORT PANEL x2

HARDWARE REQUIRED


TOOLS REQUIRED



STEP 6



PARTS REQUIRED

- 01 - LEFT PANEL x1



HARDWARE REQUIRED


TOOLS REQUIRED



STEP 7



PARTS REQUIRED

09 - TOP PANEL x1




HARDWARE REQUIRED

TOOLS REQUIRED




STEP 8

PARTS REQUIRED





HARDWARE REQUIRED

E  04


G  01

TOOLS REQUIRED




STEP 9



PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 10



PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED



STEP 11

PARTS REQUIRED


03 - DRAWER FRONT x3


04 - DRAWER LEFT PANEL x3

05 - DRAWER RIGHT PANEL x3



HARDWARE REQUIRED

A  06

B  06

C  06

TOOLS REQUIRED



STEP 12

PARTS REQUIRED

04 - DRAWER LEFT PANEL x3

05 - DRAWER RIGHT PANEL x3



10- DRAWER BACK PANEL x3

11- DRAWER BOTTOM PANEL x3

HARDWARE REQUIRED

D  12


TOOLS REQUIRED




STEP 13

PARTS REQUIRED

03 - DRAWER FRONT x1





HARDWARE REQUIRED

E  12




F  03

TOOLS REQUIRED



STEP 14

PARTS REQUIRED



FINISH