


NEVADA 2 DOOR 1 DRAWER WARDROBE

ASSEMBLY INSTRUCTIONS






IMPORTANT

FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
 - Never drag or push products as this could cause damage to the joints making it inferior.
 - We strongly recommend that you keep children away from your work area.
 - We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
 - Assemble this product as close to its final position as possible.
 - Do not place this product next to a radiator or in direct sunlight.
 - Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
 - Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
 - Make sure any spillage is wiped off immediately.
 - Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
 - For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
 - From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
 - Do not place on a wet or damp floor as staining may occur to your floor.



PARTS LIST



























Please Note:

The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Description	Quantity	Carton
01	Base-Top Panel	2	1/2
02	Left Side Panel	1	1/2
03	Right Side Panel	1	1/2
04	Front Baseboard	1	2/2
05	Back Baseboard	1	2/2
06	Back Panel	2	1/2
07	Frame	1	2/2
08	Door	2	2/2
15	Drawer Side	2	1/2
16	Drawer Back Panel	1	2/2
17	Drawer Front	1	2/2
18	Drawer Bottom	1	1/2
19	Drawer Bottom Support Bar	1	2/2


FITTINGS LIST

SEC/SW/03/22/DM1

<p>A</p>  <p>Flat Head Screw Ø6,0 x 8mm (4x)</p> <p>1/+</p>	<p>B</p>  <p>Flan Head Screw Ø3,5 x 12mm (10x)</p> <p>1/+</p>	<p>C</p>  <p>Flat Head Screw Ø4,0 x 14mm (34x)</p> <p>2/+</p>	<p>D</p>  <p>Flan Head Screw Ø4,0 x 20mm (6x)</p> <p>1/+</p>
<p>E</p>  <p>Flat Head Screw Ø4,0 x 45mm (14x)</p> <p>2/+</p>		<p>F</p>  <p>Flat Head Screw Ø4,0 x 12mm (8x)</p> <p>1/+</p>	<p>G</p>  <p>2/+ Dowel Ø6,0 x 30mm (26x)</p>
<p>H</p>  <p>Nail 10 x 10 (65x)</p> <p>5/+</p>	<p>I</p>  <p>Flan Head Screw Ø3,5 x 30mm (2x)</p> <p>1/+</p>	<p>J</p>  <p>1/+ 'L' Metallic Support (4x)</p>	<p>K</p>  <p>Washer (4x)</p> <p>1/+</p>
<p>L</p>  <p>Plastic Foot (6x)</p> <p>1/+</p>	<p>M</p>  <p>Hanging Rail Support (2x)</p>	<p>N</p>  <p>Hanging Rail (1x)</p>	
<p>O</p>  <p>Hinge (6x)</p>	<p>P</p>  <p>Hinge Plate (6x)</p>	<p>Q</p>  <p>Drawer Runners (1x)</p>	
<p>R</p>  <p>Back Panel Strip (1x)</p>		<p>S</p>  <p>Strap (2x)</p>	<p>T</p>  <p>Handle (3x)</p>
<p>U</p>  <p>Hole Plugs (16x)</p> <p>2/+</p>	<p>V</p>  <p>Glue (2x)</p>	<p>W</p>  <p>Cam Nut (2x)</p> <p>1/+</p>	<p>X</p>  <p>Cam Bolt (2x)</p> <p>1/+</p>
<p>Y</p>  <p>Door Support (2x)</p>	<p>Z</p>  <p>Flat Head Screw Ø3,5 x 25mm (1x)</p> <p>1/+</p>		

TIPS FOR FITTINGS CAM-LOCKS


WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



✓

↑


CORRECT



✗

↑


WRONG



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example beside)





STEP 1

PARTS REQUIRED


2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED







A  02
Ø6,0 x 8mm

H  02
10 x 10

L  02

Q  01

TOOLS REQUIRED





STEP 2


PARTS REQUIRED


3 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED







A  02
Ø6,0 x 8mm

H  02
10 x 10

L  02

Q  01

TOOLS REQUIRED




STEP 3

PARTS REQUIRED

2 - LEFT SIDE PANEL x1



HARDWARE REQUIRED

C  08
Ø4,0 x 14mm

M  01

P  03

TOOLS REQUIRED




STEP 4

PARTS REQUIRED

3 - RIGHT SIDE PANEL x1



HARDWARE REQUIRED

C  08
Ø4,0 x 14mm

M  01

P  03

TOOLS REQUIRED



STEP 5

PARTS REQUIRED


1A - TOP PANEL x1


1B - BASE PANEL x1

HARDWARE REQUIRED

B  04
Ø3,5 x 12mm

F  02
Ø4,0 x 12mm



G  08
Ø6,0 x 30mm

J  02

V  01

Y  02

TOOLS REQUIRED




STEP 6


PARTS REQUIRED

4 - FRONT BASEBOARD x1

5 - BACK BASEBOARD x1

HARDWARE REQUIRED



G  08
Ø6,0 x 30mm

H  02
10 x 10

L  02

V  01

TOOLS REQUIRED





STEP 7

PARTS REQUIRED





- 1A - BASE PANEL x1
- 1B - TOP PANEL x1
- 3 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

E  04
Ø4,0 x 45mm

V  01

TOOLS REQUIRED




Detail 1

Detail 12


STEP 8


PARTS REQUIRED

- 4 - FRONT BASEBOARD x1
- 5 - BACK BASEBOARD x1
- 2 - LEFT SIDE PANEL x1







HARDWARE REQUIRED

E  08
Ø4,0 x 45mm

V  01

TOOLS REQUIRED



Detail 1

Detail 12


STEP 9


PARTS REQUIRED





HARDWARE REQUIRED

TOOLS REQUIRED




6 - BACK PANEL x2

H  40
10 x 10

R  01




* For your future reference
Order Number should be here





Detail 13

STEP 10




PARTS REQUIRED




HARDWARE REQUIRED

H		02
B		06

TOOLS REQUIRED



Detail 13




Detail 14

STEP 11

PARTS REQUIRED

7 - FRAME x1






HARDWARE REQUIRED


J 02

F Ø4,0 x 12mm 06

TOOLS REQUIRED




Detail 15



Align corners



STEP 12

PARTS REQUIRED



HARDWARE REQUIRED

N 01






Detail 16

STEP 13



PARTS REQUIRED

- 15 - DRAWER SIDE x2
- 16 - DRAWER BACK PANEL x1
- 17 - DRAWER FRONT x1
- 19 - DRAWER BOTTOM SUPPORT BAR x1

HARDWARE REQUIRED

- G  10
Ø6,0 x 30mm
- V  01
Glue
- X  02

TOOLS REQUIRED




STEP 14



PARTS REQUIRED

- 15 - DRAWER SIDE x2
- 16 - DRAWER BACK PANEL x1

HARDWARE REQUIRED

- E  02
Ø4,0 x 45mm


TOOLS REQUIRED




STEP 15

PARTS REQUIRED



17 - DRAWER FRONT x1



HARDWARE REQUIRED


V  01

TOOLS REQUIRED



STEP 16

PARTS REQUIRED







HARDWARE REQUIRED

U  04

W  02


TOOLS REQUIRED




STEP 17

PARTS REQUIRED




18 - DRAWER BOTTOM x1




HARDWARE REQUIRED

H  04

TOOLS REQUIRED




Detail 18




STEP 18

PARTS REQUIRED




19 - DRAWER BOTTOM SUPPORT BAR x1



HARDWARE REQUIRED


H  06

TOOLS REQUIRED




Detail 1

Detail 18






STEP 19





PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED





STEP 20



PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 21

PARTS REQUIRED



8 - DOOR x2






HARDWARE REQUIRED

U 12

TOOLS REQUIRED




Detail 20



Detail 21

STEP 22

PARTS REQUIRED






HARDWARE REQUIRED

D Ø4,0 x 20mm 06


T 03

TOOLS REQUIRED




Detail 22

See the last page




STEP 23




PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED




Detail 23




Detail 23



Height Adjustment



Internal Adjustment







Depth Adjustment



WARNING


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.



NEVADA 3+2 DRAWER CHEST

ASSEMBLY INSTRUCTIONS







IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER


CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



After assembly use an alcohol based product/cleaner to erase the numbers printed on the parts that are visual.




PARTS LIST























Please Note:
The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Description	Quantity	Carton
01	Right Side Panel	1	1/2
02	Left Side Panel	1	1/2
03	Front Baseboard	1	1/2
04	Back Baseboard	1	1/2
05	Crossbar	2	2/2
06	Top Panel	1	2/2
07	Division Panel	1	1/2
08	Back Panel	1	1/2
09	Drawer Side	10	1/2
10	Large Drawer Back Panel	3	1/2
11	Large Drawer Front	3	2/2
12	Large Drawer Bottom	3	2/2
13	Drawer Bottom Support Bar	3	1/2
14	Small Drawer Back Panel	2	1/2
15	Small Drawer Front	2	2/2
16	Small Drawer Bottom	2	1/2



TOOLS REQUIRED



FITTINGS LIST

<p>A</p>  <p>Flat Head Screw 2/+ Ø6,0 x 10mm (16x)</p>	<p>B</p>  <p>Double Flat Head Screw 1/+ Ø4,0 x 18mm (2x)</p>	<p>C</p>  <p>Flat Head Screw 2/+ Ø4,0 x 14mm (30x)</p>	<p>D</p>  <p>Flan Head Screw 2/+ Ø4,0 x 20mm (10x)</p>
<p>E</p>  <p>Flat Head Screw 1/+ Ø3,5 x 40mm (6x)</p>	<p>F</p>  <p>Flat Head Screw 2/+ Ø4,0 x 50mm (19x)</p>	<p>G</p>  <p>2/+ Dowel Ø6,0 x 30mm (69x)</p>	<p>H</p>  <p>2/+ Nail 10 x 10 (84x)</p>
<p>I</p>  <p>1/+ Back Panel Bracket (2x)</p>	<p>J</p>  <p>2/+ Cam Nut Ø12mm (10x)</p>	<p>K</p>  <p>1/+ Washer (4x)</p>	<p>L</p>  <p>1/+ Plastic Foot (6x)</p>
<p>M</p>  <p>1/+ Flan Head Screw Ø3,5 x 30mm (2x)</p>	<p>N</p>  <p>2/+ Cam Bolt (16x)</p>	<p>O</p>  <p>2/+ Hole Plugs (8x)</p>	<p>P</p>  <p>Glue (2x)</p>
<p>Q</p>  <p>Drawer Runners (5x)</p>	<p>R</p>  <p>Back Panel Strip (1x)</p>	<p>S</p>  <p>Strap (2x)</p>	<p>T</p>  <p>Handle (5x)</p>
<p>U</p>  <p>1/+ Cam Nut Ø15mm (6x)</p>	<p>V</p>  <p>2/+ Hole Plugs (10x)</p>		




TIPS FOR FITTINGS CAM-LOCKS



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)





STEP 1

PARTS REQUIRED

2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED



G  02
Ø6 x 30

H  02
10 x 10

L  02

P  01
GLUE

TOOLS REQUIRED





STEP 2

PARTS REQUIRED

1 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED



G  02
Ø6 x 30

H  02
10 x 10

L  02

P  01
GLUE

TOOLS REQUIRED



STEP 3

PARTS REQUIRED





2 - LEFT SIDE PANEL x1

HARDWARE REQUIRED

A  08
Ø6 x 10

Q  04
LEFT

TOOLS REQUIRED




Detail 3


STEP 4

PARTS REQUIRED





1 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

A  08
Ø6 x 10

Q  04
RIGHT

TOOLS REQUIRED







Detail 5

STEP 5



PARTS REQUIRED

- 3 - FRONT BASEBOARD x1
- 4 - BACK BASEBOARD x1
- 5 - CROSSBAR x2

HARDWARE REQUIRED

- G  16
Ø6 x 30
- H  02
10 x 10
- L  02
- P  01
GLUE

TOOLS REQUIRED








STEP 6



PARTS REQUIRED

- 7 - DIVISION PANEL x1

HARDWARE REQUIRED

- B  02
Ø4.0 x 18mm
- G  03
Ø6 x 30
- P  01
GLUE
- Q  01
LEFT
- Q  01
RIGHT

TOOLS REQUIRED





STEP 7



PARTS REQUIRED

- 1 - RIGHT SIDE PANEL x1
- 3 - FRONT BASEBOARD x1
- 4 - BACK BASEBOARD x1
- 5 - CROSSBAR x2

HARDWARE REQUIRED

- F  04
Ø4 x 50
- P  01
GLUE


TOOLS REQUIRED





STEP 8

PARTS REQUIRED



- 2 - LEFT SIDE PANEL x1



HARDWARE REQUIRED

- F  04
Ø4 x 50
- P  01
GLUE

TOOLS REQUIRED



STEP 9




PARTS REQUIRED

6 - TOP PANEL x1

HARDWARE REQUIRED

N  06

TOOLS REQUIRED



STEP 10

PARTS REQUIRED




6 - TOP PANEL x1

7 - DIVISION PANEL x1

HARDWARE REQUIRED


U  02

TOOLS REQUIRED



STEP 11







PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 1

Detail 8

Cam bolt head needs to be in centre

STEP 12



PARTS REQUIRED




HARDWARE REQUIRED





TOOLS REQUIRED




Detail 10



* For your future reference Order Number should be here



Detail 11





Detail 10

STEP 13



PARTS REQUIRED

- 9 - DRAWER SIDE x10
- 10 - LARGE DRAWER BACK PANEL x3
- 13 - DRAWER BOTTOM SUPPORT BAR x3
- 14 - SMALL DRAWER BACK PANEL x2

HARDWARE REQUIRED

- G  46
- P  01

TOOLS REQUIRED




STEP 14




PARTS REQUIRED

- 11 - LARGE DRAWER FRONT x3
- 15 - SMALL DRAWER FRONT x2

HARDWARE REQUIRED

- N  10

TOOLS REQUIRED




STEP 15

PARTS REQUIRED



9 - DRAWER SIDE x6

10 - LARGE DRAWER BACK PANEL x3

HARDWARE REQUIRED

F  06
Ø4 x 50


TOOLS REQUIRED



STEP 16

PARTS REQUIRED

11 - LARGE DRAWER FRONT x3





HARDWARE REQUIRED

J  06

P  01
GLUE


TOOLS REQUIRED




STEP 17

PARTS REQUIRED




12 - LARGE DRAWER BOTTOM x3



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 18

PARTS REQUIRED




13 - DRAWER BOTTOM SUPPORT BAR x3



HARDWARE REQUIRED




TOOLS REQUIRED







STEP 19





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED





STEP 20




PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED



Detail 14



Detail 9


STEP 21

PARTS REQUIRED



9 - DRAWER SIDE x6

14 - DRAWER BACK PANEL x3

HARDWARE REQUIRED

F  04
Ø4 x 50


TOOLS REQUIRED



STEP 22

PARTS REQUIRED

15 - SMALL DRAWER FRONT x3





HARDWARE REQUIRED

J  04

P  01
GLUE


TOOLS REQUIRED




STEP 23

PARTS REQUIRED









16 - DRAWER BOTTOM x2



HARDWARE REQUIRED


H  08
10 x 10

TOOLS REQUIRED




STEP 24




PARTS REQUIRED



HARDWARE REQUIRED


H  08
10 x 10

TOOLS REQUIRED





STEP 25





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 26


PARTS REQUIRED





HARDWARE REQUIRED




TOOLS REQUIRED



X2





Detail 11




Detail 9

STEP 27

PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED


See the last page

See the last page

Detail 14




Detail 14




STEP 28

PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




TIP
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.

Detail 15

Detail 15

Detail 15

Detail 15









Detail 15


WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.



NEVADA 3 DRAWER BEDSIDE ASSEMBLY INSTRUCTIONS





IMPORTANT FOR DOMESTIC USE ONLY

PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.















- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.

TOOLS REQUIRED**PARTS LIST*****Please Note:***

The below parts have all been stamped with the part number to help identify them during assembly.

Part Number	Part Description	Quantity	Carton
1	Left Side Panel	1	1/1
2	Right Side Panel	1	1/1
3	Back Baseboard	1	1/1
4	Front Baseboard	1	1/1
5	Top Panel	1	1/1
6	Back Panel	1	1/1
16	Drawer Side	6	1/1
17	Drawer Back Panel	3	1/1
18	Drawer Front	3	1/1
19	Drawer Bottom	3	1/1


FITTINGS LIST

<p>A</p>  <p>Flat Head Screw Ø6,0 x 8mm (12x)</p> <p>2/+</p>	<p>B</p>  <p>Flat Head Screw Ø4,0 x 14mm (18x)</p> <p>2/+</p>	<p>C</p>  <p>Flan Head Screw Ø4,0 x 20mm (6x)</p> <p>1/+</p>	<p>D</p>  <p>Flat Head Screw Ø4,0 x 45mm (10x)</p> <p>1/+</p>
<p>E</p>  <p>Dowel Ø6,0 x 30mm (36x)</p> <p>2/+</p>	<p>F</p>  <p>Nail 10 x 10 (40x)</p> <p>5/+</p>	<p>G</p>  <p>Cam Bolt (10x)</p> <p>1/+</p>	<p>H</p>  <p>Cam Nut Ø12mm (10x)</p> <p>1/+</p>
<p>I</p>  <p>Plastic Foot (4x)</p> <p>1/+</p>	<p>J</p>  <p>Hole Plugs (16x)</p> <p>2/+</p>	<p>K</p>  <p>GLUE</p> <p>Glue (2x)</p>	<p>L</p>  <p>Handle (3x)</p>
<p>M</p>  <p>Drawer Runners (3x)</p>	<p>N</p>  <p>Flan Head Screw Ø3,5 x 12mm (2x)</p> <p>1/+</p>		

TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE


✓



↑


CORRECT

✗






↑

WRONG



Cam bolt head needs to be in centre

CAMBOLT
Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)





STEP 1

PARTS REQUIRED

1 - LEFT SIDE PANEL x1

HARDWARE REQUIRED




E  02
Ø6,0 x 30mm

F  02
10 x 10

I  02

K  01
GLUE

TOOLS REQUIRED





STEP 2

PARTS REQUIRED

2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED




E  02
Ø6,0 x 30mm

F  02
10 x 10

I  02

K  01
GLUE

TOOLS REQUIRED





STEP 3





PARTS REQUIRED

2 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED

- A  06
Ø6,0 x 8mm
- M  03
RIGHT

TOOLS REQUIRED





STEP 4





PARTS REQUIRED

1 - LEFT SIDE PANEL x1

HARDWARE REQUIRED

- A  06
Ø6,0 x 8mm
- M  03
LEFT

TOOLS REQUIRED




STEP 5

PARTS REQUIRED

3 - BACK BASEBOARD x1


4 - FRONT BASEBOARD x1

HARDWARE REQUIRED

E  08
Ø6.0 x 30mm

K  01

TOOLS REQUIRED



Detail 1

STEP 6


PARTS REQUIRED

2 - RIGHT SIDE PANEL x1

3 - BACK BASEBOARD x1




4 - FRONT BASEBOARD x1

HARDWARE REQUIRED


D  02
Ø4.0 x 45mm

K  01

TOOLS REQUIRED



Detail 1




Detail 6


STEP 7

PARTS REQUIRED

1 - LEFT SIDE PANEL x1





HARDWARE REQUIRED


D  02
Ø4,0 x 45mm

K  01

TOOLS REQUIRED



Detail 1




Detail 6

STEP 8




PARTS REQUIRED

5 - TOP PANEL x1


HARDWARE REQUIRED

G  04

TOOLS REQUIRED




Detail 2



STEP 9

PARTS REQUIRED

5 - TOP PANEL x1






HARDWARE REQUIRED


H  04

K  01


TOOLS REQUIRED



Detail 1



Detail 7




Cam bolt head needs to be in centre


STEP 10

PARTS REQUIRED

6 - BACK PANEL x1





HARDWARE REQUIRED



F  12
10 x 10

N  02
Ø3,5 x 12mm


TOOLS REQUIRED




Detail 8



* For your future reference
Order Number should be here



Detail 8



Detail 16

STEP 11


PARTS REQUIRED


16 - DRAWER SIDE x6

17 - DRAWER BACK PANEL x3

18 - DRAWER FRONT x3




HARDWARE REQUIRED

E  24
Ø6 x 30mm

G  06

K  01
GLUE

TOOLS REQUIRED




STEP 12

PARTS REQUIRED



16 - DRAWER SIDE x6

17 - DRAWER BACK PANEL x3

HARDWARE REQUIRED

D  06
Ø4,0 x 45mm


TOOLS REQUIRED



STEP 13

PARTS REQUIRED



18 - DRAWER FRONT x3



HARDWARE REQUIRED


K  01

TOOLS REQUIRED



STEP 14

PARTS REQUIRED






HARDWARE REQUIRED

H  06

J  12


TOOLS REQUIRED



STEP 15

PARTS REQUIRED





19 - DRAWER BOTTOM x3



HARDWARE REQUIRED


F 10 x 10 12

TOOLS REQUIRED



STEP 16




PARTS REQUIRED



HARDWARE REQUIRED


F 10 x 10 12

TOOLS REQUIRED





STEP 17





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



STEP 18




PARTS REQUIRED



HARDWARE REQUIRED





TOOLS REQUIRED



Detail 11

STEP 19

PARTS REQUIRED





HARDWARE REQUIRED




TOOLS REQUIRED

TIP
If desired, after assembly use an alcohol cleaner to erase the number printed on the parts.




STEP 20



PARTS REQUIRED




HARDWARE REQUIRED




TOOLS REQUIRED



Drawer Adjustment



Drawer Lock



Detail 26