




- 1** Prepare Wheel Barrow Handle (a) for assembly.



- 2** Place the Wheelbarrow Tray (b) onto the handle assembly so that all holes are aligned. Place 2 x Wheelbarrow Legs (c) to the underside of the Handle, as shown, ensuring all holes are aligned. Insert 4 x M8 x 50 Bolts (i) with flat washers through the holes in Tray, Handles and Legs, and fit spring washers & nuts, then tighten. Attach 2 x Flat Cross Braces (d) to the backs of the Legs using 4 x M8 x 20 Bolts, nuts & washers (j), as shown.



- 3** Attach 2 x Front Supports (h) to the wheelbarrow tray as shown, using 2 x M8 x 20 Bolts, nuts & washers (j). Align the holes in the bottom of the Front Supports with the holes in the Wheelbarrow Handle. Slide the Wheel (e) onto the Axle (f) and then slide on the 2 x Axle Brackets (g). Secure the Axle Brackets to the front fork of the Wheelbarrow Handle and the lower ends of the Front Supports using 2 x M8 x 70 Bolts, nuts and washers (k).



- 4** Using screwdriver and spanner, tighten all nuts and bolts securely.



WARNING - DO NOT OVER - INFLATE YRE - MAXIMUM RECOMMENDED PRESSURE 30PSI or 210kPa.