



Please give us a chance to make it right and do better !

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP !

US office: Fontana

UK office: Ipswich

AU office: Truganina

DE office: Hamburg

FR office: Saint Vigor d'Ymonville

PL office: Gdańsk



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



US: cs.us@costway.com

UK: cs.uk@costway.com

AU: cs.au@costway.com

COSTWAY®










USER'S MANUAL

Mini Fridge ES10098GB

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

-  Please read all instructions carefully.
-  Retain instructions for future reference.
-  Separate and count all parts and hardware.
-  Read through each step carefully and follow the proper order.
-  We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
-  Always place the product on a flat, steady and stable surface.
-  Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Product Characteristics


- This thermoelectric cooler and warmer is a great way to keep food and drinks cool during the summer and warm during the winter. Perfect to use at home, in your office, or in your car. Wherever you are, you can always enjoy fresh food and drinks.
- Easily portable and sleek, it makes a stylish choice for any setting.
- Shelves and container baskets are removable. To remove shelves: gently push shelves up and slide out. To remove container basket: gently push up and lift basket from slots.
- Included AC and DC plugs make it ideal for indoor and outdoor use. This thermoelectric cooler/warmer unit is ultra-durable, eco-friendly and safe to use, its semiconductor operation consumes minimal power and uses no compressors, cryogen, refrigerants, or Freon.

Applications

- The best place to store all your beauty essentials, extend the life of cosmetics, and keep your masks chilled for extra cooling sensation and let you relax after a long day. The surface of the LED vanity mirror can be adjusted to three levels of brightness.
- At home, keep snacks and drinks at hand while enjoying your favorite shows and movies uninterrupted.
- Store on top of your office desk and use it as your own personal mini fridge.

- Great for picnics, camping and fishing trips when cold drinks and warm food are a necessity.
- Ideal for long-distance travelers, commuters, and taxi drivers who want to keep food and drinks fresh nearby.
- Perfect for parents who need to store breast milk at a desired temperature.
- Safely store medications that need to be kept at a specific temperature.

Getting Started



1. **Before plugging in the cooler/warmer unit:** make sure the switch on the back of the unit is set to the OFF setting.

2. **A minimum 5cm (2") vent clearance** is required for proper ventilation.

3. **Plugging in your unit:**

For home application: Use the supplied AC power cord by inserting AC connector into unit's AC port and inserting AC plug into wall outlet.

This unit ONLY works on 220-240V.

For motor vehicle application: Car engine **MUST** be turned on first before plugging in the cooler/warmer. This precaution prevents a power surge that can cause the unit to overheat and/or becoming a potential fire risk. Use the supplied DC power cord and insert DC connector into unit's DC port and the DC plug into the appropriate cigarette-lighter outlet.

4. Turning on your unit:

For Cooling: Set the power switch to the COLD setting. A green light will turn on to indicate that the unit is in cooling mode.

For Warming: Set the power switch to the WARM setting. A red light will turn on to indicate that the unit is in heating mode.

5. Adjusting the intensity of the light

Three levels of brightness can be adjusted



WARNING

PLEASE READ THESE DIRECTIONS CAREFULLY BEFORE USING THIS COOLER / WARMER UNIT TO ENSURE PROPER OPERATION.

1. To ensure optimal performance, keep the cooler/warmer unit's fans clear of dirt and debris. A stuck fan will overheat the unit and can pose a potential fire hazard.
2. Do not place any cloth or paper products on the unit.
3. When plugging in the unit, ensure that the power cord is inserted tightly into the socket. A loose socket can cause damage or fire.
4. When using the unit in a car/vehicle with the DC power cord, the vehicle's engine must be turned on first. When the engine is running, the unit can then be plugged into the vehicle's adapter. This prevents a power surge and potential property damage, injury, and/or fire.
5. Keep the unit away from flammable items and running water to prevent damage, injury, and/or fire.
6. DO NOT attempt to open, break or refit the appliance.
7. This unit ONLY works on 220-240V.
8. To switch temperature control, the unit must be turned to the OFF setting for 30 minutes before shifting the unit from COLD to WARM.
9. DO NOT submerge or rinse under running water.
10. When packing the unit, do not place upside-down.
11. Avoid dropping or banging the unit.
12. DO NOT leave the appliance in the rain.

13. For adult use, and children can only use the product under adult supervision. This is not a toy. Children should not play with this cooler and warmer unit. For people with reduced physical, sensory, and/or mental capabilities, use precaution and follow all instructions when operating this unit to ensure safety.

14. Always keep ventilation openings clear of obstruction.

15. DO NOT use other electrical appliances inside the food storage compartments of the appliance.

16. If the power cord that is supplied with the cooler and warmer unit is damaged in any way-DO NOT attempt to repair it; damaged power cords must be replaced by the manufacturer.